

Water Cooled Ultimate Chiller Solution

Model UCW/H 30, 50, 70, 85

Installation, Operation & Maintenance Manual



CLIMA  COOL®
THE ULTIMATE CHILLER SOLUTION®



Table of Contents

Introduction	1	Pre-Startup Check List.....	26
Pre-Installation	2	Startup.....	27-28
Physical Data.....	3	Superheat & Subcooling Flowchart	29
Dimensional Data and Drawings	4	Startup and Warranty Form	30
Rigging and Lifting Procedures	5	Chiller Operation and Maintenance	31
Mounting Rail and Vibration Isolation	6	Heat Exchangers	32
Recommended Service Clearances.....	7	Cleaning Arrangement	33
Model Key	8	Operational Limitations	34
Unit Installation	9-11	Compressor Information	35
Electrical Connection.....	12	Refrigeration Circuit Diagram	36-37
Voltage/Phase Monitor Wiring.....	13	Refrigeration System Re-Processing and Charging	38
Water Piping.....	14-15	Engineering Guide Specifications	39-40
Water Piping Configurations	16	Options and Accessories.....	41
Hydronic Refrigeration	17	Stainless Steel Strainer Option	42-46
Part-Load Performance Advantage	18	WYE Strainers	47-48
Filling the Water System.....	19	Basket Strainers	49-50
Water Treatment	20	Electrical Data.....	51-52
Water Temperature Requirements	21	Power Distribution Drawing.....	53
Condenser & Evaporator Water Pressure Drop Charts.....	22	Wiring Diagrams.....	54-63
Glycol Performance Adjustment Factors Charts	23-24	Troubleshooting Guide	64-65
Pre-Startup	25	Warranty Certificate	66

Introduction

General Description

ClimaCool's dedication to energy and environmental leadership led to the Ultimate Chiller Solution design. Available in 30, 50, 70 and 85 tons, each module is compact, redundant, maneuverable, efficient, reliable and serviceable. Combined tonnages can obtain specific project turndown and capacity requirements from 30 to 1,000 tons per bank while having the ability to accommodate future growth and expansion needs.

The UCW/H model can offer hot gas bypass, heat pump and heat recovery options utilizing environmentally friendly R-410A refrigerant for Green building designs.

Safety

Throughout this manual warning, danger, caution and attention notices appear. Read these items carefully before attempting any installation, service or troubleshooting of the equipment. All labels on unit access panels must be observed.

DANGER: Immediate hazardous situation which, if not avoided, will result in death or serious injury.

WARNING: Potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION: Potentially hazardous situation or an unsafe practice which, if not avoided, could result in minor or moderate injury or product or property damage.

ATTENTION: Notification of installed, operation or maintenance information which is important, but not hazard related.

CAUTION/ATTENTION	
Single wall heat exchanger, not suitable for potable water connection.	Single paroi échangeur, non approprié pour le raccordement d'eau potable.

ATTENTION
Do not defeat, cap, add piping to the outlet of the valve or attempt to change the relief setting.

WARNING/AVERTISSEMENT	
	
WATER AND REFRIGERANT SYSTEMS UNDER PRESSURE	EAU ET FRIGORIGÈNE EQUIPEMENTS SOUS PRESSION
<ul style="list-style-type: none"> Isolate/Lockout source and relieve pressure BEFORE servicing equipment. Failure to relieve pressure may result in property damage, serious bodily injury or death! 	<ul style="list-style-type: none"> Isoler la source / de verrouillage et de soulager la pression avant entretien de l'équipement. Le défaut de soulager la pression peut entraîner des dommages matériels, des blessures corporelles graves ou la mort!

CAUTION/ATTENTION	
Excessive Chlorine, undissolved solids and other improper water conditions WILL DAMAGE the internal heat exchanger & WILL VOID YOUR WARRANTY!	Chlore excessive, solides non dissous et les autres impropres conditions de l'eau, ENDOMMAGERA l'échangeur de chaleur interne et ANNULERA VOTRE GARANTIE!

WARNING/AVERTISSEMENT	
Very Hot Water!	L'eau Très Chaude!

CAUTION/ATTENTION	
Use only copper conductors for field installed wiring. Unit terminals are not designed to accept other types of conductors.	Utilisez uniquement des conducteurs en cuivre pour le câblage. Bornes de l'unité ne sont pas conçues pour accepter d'autres types de conducteurs.

WARNING/AVERTISSEMENT	
Disconnect power supply (ies) before servicing. Refer servicing to qualified service personnel. Electric shock hazard. May result in injury or death!	 Débrancher avant d'entreprendre le dépannage de l'appareil. Consulter un réparateur qualifié pour le dépannage. Risque de choc électrique. Résultat de mai dans dommages ou la mort!
CAUTION/ATTENTION	
Unit to be serviced by qualified personnel only. Refrigerant system under pressure. Relieve pressure before using torch. Recover refrigerant and store or dispose of properly.	 Conifer la maintenance à un technicien qualifié. Le système frigorifique sous pression. Décompresser avant d'exposer à la flamme. Récupérer le frigorigène et le stocker ou le détruire correctement.

ATTENTION
To avoid the release of refrigerant into the atmosphere, the refrigerant circuit of this unit must be serviced only by technicians who meet local, state and federal proficiency requirements.
All refrigerant discharged from this unit must be recovered WITHOUT EXCEPTION. Technicians must follow industry accepted guidelines and all local, state and federal statutes for the recovery and disposal of refrigerants.
If a compressor is removed from the unit, system refrigerant circuit oil will remain in the compressor. To avoid leakage of compressor oil, the refrigerant lines of the compressor must be sealed after it is removed.

CAUTION/ATTENTION	
3 PHASE SCROLL COMPRESSOR UNITS	UNITÉ DE COMPRESSEUR SCROLL 3-PHASE
If this unit uses a 3 Phase Scroll Compressor, the following instructions MUST BE followed: <ul style="list-style-type: none"> Unit power supply MUST BE wired in the proper sequence to avoid damage to the 3 Phase Scroll Compressor; Scroll Compressors with INCORRECT rotation show the following characteristics: <ul style="list-style-type: none"> High sound level; High suction pressure and low discharge pressure; Low current draw. If any of the three above characteristics exist, swap two of the three supply wires at the disconnect and recheck compressor for incorrect rotation. 	Si cet appareil utilise compresseur scroll 3-Phase, les instructions suivantes doivent être suivies: <ul style="list-style-type: none"> L'alimentation de l'appareil doit être monté dans l'ordre correct pour éviter endommager le compresseur scroll 3-Phase Compresseurs scroll avec rotation incorrecte montrent les caractéristiques suivantes: <ul style="list-style-type: none"> Haut niveau de son; Pression d'aspiration élevée et une faible pression de décharge; Faible ampérage Si l'un des trois éléments mentionnés ci-dessus sont remplis, échanger deux des trois lignes électriques alimentant l'interrupteur de sécurité et vérifier la rotation du compresseur.

Pre-Installation

Inspection

Upon receipt of equipment, carefully check the shipment against the bill of lading and inspect each chiller for any damage incurred during shipment. Thoroughly check for any visible damage of control panels and electrical and/or refrigeration components or broken copper lines. The carrier must make proper notation of any damages or shortages on all copies of the bill of lading and complete a common carrier inspection report prior to your final acceptance of the shipment. **Note:** It is the responsibility of the purchaser to file all necessary claims with the carrier. In addition, please notify the ClimaCool Customer Service Department at 405.815.3000 or customerservice@climacoolcorp.com of all damage immediately.

Storage

Chillers should be stored in an upright position and kept in a clean, dry area.

Handling of Modules

Carefully remove the module's packaging. The chiller's steel base cutouts provide maneuverability by forklift or pallet jack into its final position (See Rigging and Lifting Procedures on page 5). Verify that all header grooved couplings and mounting hardware kits are on site prior to connecting the modules. **Note:** Consult factory for handling other than in the upright position.

Rigging and Lifting

Each module should be lifted using a pallet jack or fork lift. If it is necessary to utilize a crane for rigging or lifting, each module shall be lifted using lifting straps and spreader bars using rigging points identified on Rigging and Lifting Procedures on page 5.

Warranty

To ensure proper equipment longevity, design performance and reliability, all ClimaCool chillers must be installed, operated and maintained in accordance with ClimaCool IO&M manuals. Water quality is of the utmost importance for the proper care and maintenance of your modular chiller system. Regular treatment of the water will increase longevity of your system. **Failure to provide adequate filtration or treatment of evaporator and condenser water will void the ClimaCool module's warranty.** A factory authorized technician is required to perform the startup of your ClimaCool chiller. Please contact the ClimaCool Customer Service Department at 405-815-3000 or technicalsupport@climacoolcorp.com to schedule. **There is a minimum of three (3) weeks notice required to schedule your factory startup.**

Physical Data


Model UCW/H Module and Compressor		30	50	70	85
Capacity (tons) ¹		31.7	51.5	67.2	82.8
kW/Ton		0.738	0.746	0.744	0.740
Full-Load EER ²		16.3	16.1	16.1	16.2
Refrigerant Circuits (quantity)		2	2	2	2
Compressor Type		Scroll	Scroll	Scroll	Scroll
Compressor Quantity		2	2	2	2
Compressor Nominal Hp (per circuit)		15	25	35	40
Refrigerant Charge R-410A (lbs)		30	55	60	80
Module Operating Weight w/Water (lbs) ³		1565	2405	2515	3075
Module Shipping Weight (lbs) ⁴		1375	2085	2195	2610
Model UCW/H Condenser		30	50	70	85
Heat Exchanger (type)		Brazed Plate	Brazed Plate	Brazed Plate	Brazed Plate
Independent Refrigerant Circuits (quantity)		2	2	2	2
Water Storage Volume HX Only (gals)		3.2	6.1	7.3	11.4
Water Storage Volume HX Plus Main Headers (gals)		13.1	16.7	17.9	26.2
Maximum Design Working Pressure - Water Side (psi)		300	300	300	300
Header Water Connections - Inlet/Outlet (inches) ⁵		6	6	6	8
Model UCW/H Evaporator		30	50	70	85
Heat Exchanger (type)		Brazed Plate	Brazed Plate	Brazed Plate	Brazed Plate
Independent Refrigerant Circuits (quantity)		2	2	2	2
Water Storage Volume HX Only (gals)		2.8	5.1	6.5	9.7
Water Storage Volume HX Plus 6" Main Headers (gals)		12.8	15.7	17.1	24.5
System Volume (gals) ⁶	Min	180	300	420	510
Maximum Design Working Pressure - Water Side (psi)		300	300	300	300
Header Water Connections - Inlet/Outlet (inches) ⁵		6	6	6	8

Notes:

1. Ratings in accordance with AHRI Standard 550/590.
2. Tonnage ratings conditions: 44°F leaving chilled water temperature, 85°F entering condenser water temperature, flow rates are 3 gpm per ton through the condenser with a fouling factor of .00025 hr-ft²-°F/Btu and 2.4 gpm per ton through the evaporator with a .0001 hr-ft²-°F/Btu fouling factor.
3. Module operational weight includes water, compressor oil, and refrigerant charge. Multiply times the number of modules for a total system operational weight.
4. Unit shipping weight includes refrigerant charge, compressor oil and packaging.
5. Main header water/fluid connections are 6" grooved coupling for the 30, 50 and 70 ton modules. The 85 ton module uses 8" grooved couplings.
6. Required to provide stable operation. Storage/buffer tanks in return piping may be utilized to meet the minimum volume requirements.
7. 85 ton module cannot be directly coupled with 30, 50 or 70 ton modules due to a difference in header and frame size.



Dimensional Data and Drawings



LOAD WATER PIPING CONFIGURATION ARRANGEMENT (HEADER "A")			
UCW	UCH HEAT RECOVERY	UCH HEAT PUMP (Cooling Priority)	UCH HEAT PUMP (Heating Priority)
CHILLED WATER OUTLET	CHILLED WATER OUTLET	LOAD WATER OUTLET	LOAD WATER INLET
LOAD WATER PIPING CONFIGURATION ARRANGEMENT (HEADER "B")			
UCW	UCH HEAT RECOVERY	UCH HEAT PUMP (Cooling Priority)	UCH HEAT PUMP (Heating Priority)
CHILLED WATER INLET	CHILLED WATER INLET	LOAD WATER INLET	LOAD WATER OUTLET

UNIT DIMENSIONS (IN INCHES)

Model UCW/H	Voltage	A Unit Width (in.)	B Unit Height (in.)	C Header Width (in.)	D Unit Depth (in.)	E Header Location	F Header Location	G Header Location	H Header Location	I Header Location	J Header Location	K Header Location	Header Connection (in.) ¹
030	208/230/460/575/3/60	34	65 1/8	34 1/4	55 1/2	41 1/4	27 1/2	19	9 1/4	58	58	47 1/2	6
050	208/230/460/575/3/60	34	65 1/8	34 1/4	55 1/2	41 1/4	27 1/2	19	9 1/4	58	58	47 1/2	6
070	208/230/460/575/3/60	34	65 1/8	34 1/4	55 1/2	41 1/4	27 1/2	19	9 1/4	58	58	47 1/2	6
085	208/230/460/575/3/60	34	72	34 1/4	67	52 5/8	29 3/4	18 5/8	7 1/2	60 3/4	54 3/4	48	8

Note:

1. The model UCH085 cannot be directly coupled with models UCH030, 050 and 070 due to differences in header and frame size.

Rigging and Lifting Procedures

Rigging

Each module should be lifted using lift straps threaded through the steel base cutouts and a spreader bar.

Note: If no spreader bar is used, damage to the module may occur.

Figure 1






Figure 2



Lifting and Transporting Modules

Pallet jacks or forklifts are required for lifting and transporting the module. Each module has base cutouts provided for ease of maneuverability. 60" forks are recommended to prevent damage to chiller base.

Figure 3



Mounting Rail and Vibration Isolation

ClimaCool recommends locking down the chiller to a concrete base or to three (3) 4" base mounting rails using the six (6) bolt holes provided in each base pan. Due to the low vibration of the modules, the application of spring isolators or pads is not required. Should isolators or pads be desired install in accordance with Figures 4 and 5.

Figure 4 - Spring Vibration Isolators Option






Figure 5 - Vibration Isolation Pads Option



Note: Size and weight distribution is to be determined by a qualified structural engineer per individual job requirements.


Recommended Service Clearances



Notes:

1. Allow 36" clearance for electrical panels and 30" clearance for rear service access to modules.
2. Allow a minimum of 18" height clearance for 30, 50 and 70 ton modules. Allow a minimum of 24" height clearance for 85 ton modules.
3. Local building and/or electrical codes may require additional clearance. Consult applicable codes.

Ultimate Chiller Solution Model Key



Unit Installation

Unit Placement

ClimaCool modular chillers must be installed in a conditioned and dehumidified space. The minimum foundation requirement for the chiller is a level surface capable of bearing the combined operating weight of the modules (See Physical Data on page 3).

Service Access

The recommended service clearances are 36" for front access, 18" height clearance for 30, 50 and 70 ton modules, and 24" height clearance for 85 ton module, 30" for rear access and at least 12" for side clearance or as required for field piping (See Recommended Service Clearances on page 7). Local building or electrical codes may require additional clearance – please consult applicable codes.

Draining

When performing standard maintenance procedures such as flushing a heat exchanger, it will be necessary to isolate either heat exchanger. ClimaCool modular chillers offer optional water isolation valves for this purpose. Access to a floor drain is helpful when performing standard maintenance procedures. **Warning: Water valves must be reopened after flushing is complete.**

Assembling Modules

ClimaCool recommends locking down the chiller to a concrete base or to three (3) 4" base mounting rails using the six (6) bolt holes provided in each base pan. Although the compressors are installed on anti-vibration mountings, further isolation of the chiller from the structure is recommended by installing vibration-eliminating springs or pads under the base rails on which the chiller will rest (See Mounting Rail and Vibration Isolation on page 6). One module should be chosen as the reference module and carefully located.

Field installed mounting accessories are provided for adjoining each module.

- Header grooved coupling kits containing four (4) grooved couplings with gaskets
- Mounting hardware kit containing necessary bolts, spacers, nuts and washers

Figure 6: Mounting Hardware Kit



- Header bank end cap kit containing four (4) grooved couplings with gaskets and four (4) end caps

Field installing the mounting hardware kit will assist with alignment of the modules in a bank and eliminate offset inconsistencies. The 1/2" mounting holes are provided on sides of the unit base pan. First module should be set, set adjacent unit on mounting surface roughly aligned 1 1/2 inches away from the first unit. While holding spacer in place work through first modules front base cutout to place a washer and insert bolt through front mounting hole and spacer. Repeat the process for the rear mounting hole. Line up mounting hole of adjacent module with bolt from previous module and working through adjacent modules front base cutout place a washer, split lock washer and nut. Using the appropriate tools tighten hardware assembly until seated.

Inspect the pipe ends to ensure they are free from any indentations, projections, roll marks or other harmful surface defects such as loose paint, scale, dirt, chips, grease and rust. Inspect the grooved coupling gasket for any defects. Apply a thin layer of silicone or other non-petroleum lubricant to the sealing lips of the gasket as well as to the exterior of the gasket. Install gaskets on the pipe ends of one of the two modules to be mated. **Be sure the gasket is completely on the pipe to avoid damage in the next step.** Move the second module into position and line up the piping. Ensure you are maintaining alignment for any additional modules to be added. When pipe ends are aligned, slide the gasket over the ends and center it between the grooves. No part of the gasket should protrude into the groove of either pipe end. Place the coupling halves over the gasket and make sure that the coupling keys (the part that goes into the groove) are engaged into the grooves. Insert the bolts and install nuts to hand tight. Ensure the oval neck of the bolt engages into the bolt hole of the housing. **Tighten nuts alternately and equally until the bolt pads meet and make metal to metal contact.** Tighten nuts by another 1/4 to 1/2 turn to make sure the nuts and bolts are snug and secure; the use of a torque wrench is usually not required. **Uneven tightening of bolts may cause the gasket to be pinched resulting in immediate or delayed leaks.**

Header Insulation

Chilled water piping is pre-insulated on each module at the factory (See Figure 7 - Header Insulation) with 3/4" closed cell insulation. After bolting all modules together and leak testing, the entire coupling connection will need to be insulated by the installing contractor.

Unit Installation

Figure 7: Header Insulation



Sound Attenuation Panels and Gasket

Attenuation panels are enclosures made of 18 gauge galvanized steel with powder coat paint finish and fiberglass insulation. Panel package includes one (1) upper panel made out of four (4) sections and one (1) lower panel for each side of bank (field installed), four (4) panels for each module in the bank (factory installed) and gasket sealant tape for installation between modules. Install panels by setting in place and locking down with the half turn latches or self tapping screws. **Note: Panel package includes a compressed 1" x 1" gasket sealant tape for installation between modules. Install the tape on the outer frame on the side of one module prior to installing the adjacent modules. See Figure 8.**

Figure 8: Gasket Installation Between Modules



Grooved Couplings Installation

Inspect the pipe ends to ensure they are free from any indentations, projections, roll marks, or other harmful surface defects such as loose paint, scale, dirt, chips, grease and rust. Inspect the grooved coupling gasket for any defects. Grooved couplings are used to adjoin a bank of modules. This requires the temporary removal of all top, back and side sheet metal panels to obtain additional access to the headers. With the first unit positioned, the couplings can be installed using the following recommended instructions:

- Review Figure 9, UCW/H Side View below.
- Headers are numbered indicating the easiest order of coupling installation.

- UCW/H chillers should have couplings installed on headers 1, 4 from the top and 2, 3 from the back of the unit.

Figure 9 - UCW/H Side View



- Remove the rubber gasket from the coupling.
- Apply a thin layer of silicone or other non-petroleum lubricant to both the inner and outer surface of the gasket to reduce friction.
- Slide the gaskets on the headers as shown in Figure 10.
- Be sure the gasket is completely on the pipe to eliminate any damage to the gasket.

Figure 10



- With gasket in place on each header of the positioned unit (see Figure 11), move the second module into position and line up the piping. Ensure alignment is maintained for any additional modules to be added.

Figure 11



Unit Installation

- Open the coupling by completely removing one bolt and nut (see Figure 12).
- Back the other nut off as far as possible while still keeping the coupling intact.
- Install with the nuts facing up for fastening.
- When the pipes ends are aligned, slide the gasket over the ends and center it between the grooves.
- No part of the gasket should protrude into the groove of either pipe end.
- Place coupling halves over the gasket and make sure that the coupling keys (the part that goes into the groove), are engaged into the grooves.

Figure 12



- Insert the previously removed bolt from the bottom to re-attach the two sides of the coupling (see Figure 13).
- **Tighten nuts alternately and equally until the bolt pads meet and make metal-to-metal contact.**
- Tighten nuts by another $\frac{1}{4}$ to $\frac{1}{2}$ turn to make sure the nuts and bolts are snug and secure, the use of a torque wrench is usually not required.
- **Uneven tightening of bolts may cause the gasket to be pinched resulting in immediate or delayed leaks.**
- Replace all sheet metal panels.

Figure 13



Electrical Connection

The power for all modules is taken from a suitable circuit breaker/fused disconnect power supply within the main panel. The electrical service enters the individual modules through the top into the module's control panel enclosure. Proper grounding of the module is mandatory. Before carrying out any electrical work, confirm that the main supply is isolated. A typical power wiring is located on page 47 – Power Distribution Drawing. Knockout drawings are provided. Do not drill into cabinet; shavings can damage electronic components. The power for all individual modules shall be in compliance with all local and national codes.

CoolLogic Control System Wiring

A separate 115 volt power supply is required to power the CoolLogic Master Control Panel. Communication between the Master Control Panel and chiller modules requires a simple two-conductor 18 AWG shielded cable rated at 60°C minimum, daisy chain connection. **Control wiring cannot be installed in the same conduit as line voltage wiring or with wires that switch highly inductive loads such as contactor and relay coils.** Refer to the Power Distribution Drawing on page 47 of this manual for more information. All wiring shall be in compliance with all local and national codes.

Electrical Phase Sequencing

Proper clockwise rotation for scroll compressor motors is important to prevent damage to the compressors. ClimaCool recommends the use of a phase sequence indicating instrument following the manufactures directions. An alternative is to “bump test” the compressors one at a time with pressure gauges attached to the high and low gauge ports of the compressors to check for proper rotation. Energize the compressor for a few seconds to ensure the discharge pressure gauge increases significantly. If the discharge pressure does not increase, proper rotation is reversed. Compressor rotation can be reversed by opening the main electrical disconnect and switching any two of the main power supply leads feeding that compressor's contactor.

Proper Voltage Balance

Occasionally, in three phase circuits, a voltage imbalance occurs between phases. It is not recommended to operate equipment when an imbalance greater than 2% occurs. This causes motors to run at high temperatures and may affect their longevity. The following example describes how to calculate the average voltage of the three phases to see if the imbalance is greater than 2%.

Example: Line 1 = 226v Line 2 = 230v Line 3 = 228v

The average is: $(226+230+228) / 3 = 228v$

Next, $[100(228-226)] / 228 = 0.9\%$

The voltage imbalance of the three phase circuit is 0.9%. This is well under the 2% range.

Voltage/Phase Monitor


Voltage/phase monitors are factory supplied for field installation with the CoolLogic Master Control Panel. The voltage/phase monitor helps guard the chiller bank against voltage fluctuations, phase failure or phase reversal conditions which could void your warranty. The voltage/phase monitor has three wires that connect to the main three phase power chiller bank input. Two low voltage control wires are connected to the CoolLogic Master Control Panel. Do not install control wiring in the same conduit as line voltage wiring or with wires that switch highly inductive loads such as contactor and relay coils. **Note: It is mandatory to install one (1) monitor per bank at main power distribution panel to monitor voltage and phasing of power to the modules. See Wiring Diagram on page 13.**

CAUTION/ATTENTION	
Use only copper conductors for field installed wiring. Unit terminals are not designed to accept other types of conductors.	Utilisez uniquement des conducteurs en cuivre pour le câblage. Bornes de l'unité ne sont pas conçus pour accepter d'autres types de conducteurs.

WARNING/AVERTISSEMENT	
Disconnect power supply (ies) before servicing. Refer servicing to qualified service personnel. Electric shock hazard. May result in injury or death!	 Débrancher avant d'entreprendre le dépannage de l'appareil. Consulter un réparateur qualifié pour le dépannage. Risque de choc électrique. Résultat de mai dans dommages ou la mort!
CAUTION/ATTENTION	
Unit to be serviced by qualified personnel only. Refrigerant system under pressure. Relieve pressure before using torch. Recover refrigerant and store or dispose of properly.	 Confiner la maintenance à un technicien qualifié. Le système frigorifique sous pression. Décompresser avant d'exposer à la flamme. Récupérer le frigorigène et le stocker ou le détruire correctement.

CAUTION/ATTENTION	
3 PHASE SCROLL COMPRESSOR UNITS	UNITÉ DE COMPRESSEUR SCROLL 3-PHASE
If this unit uses a 3 Phase Scroll Compressor, the following instructions MUST BE followed: <ul style="list-style-type: none"> Unit power supply MUST BE wired in the proper sequence to avoid damage to the 3 Phase Scroll Compressor; Scroll Compressors with INCORRECT rotation show the following characteristics: <ul style="list-style-type: none"> High sound level; High suction pressure and low discharge pressure; Low current draw. If any of the three above characteristics exist, swap two of the three supply wires at the disconnect and recheck compressor for incorrect rotation. 	Si cet appareil utilise compresseur scroll 3-Phase, les instructions suivantes doivent être suivies: <ul style="list-style-type: none"> L'alimentation de l'appareil doit être monté dans l'ordre correct pour éviter endommager le compresseur scroll 3-Phase Compresseurs scroll avec rotation incorrecte montrent les caractéristiques suivantes: <ul style="list-style-type: none"> Haut niveau de son; Pression d'aspiration élevée et une faible pression de décharge; Faible ampérage Si l'un des trois éléments mentionnés ci-dessus sont remplies, échanger deux des trois lignes électriques alimen tant la interrupteur de sécurité et vérifier la rotation du compresseur.

Voltage/Phase Monitor Wiring



		MOTOR SAVER PHASE MONITOR	
		Typical phase monitor installation	
SIZE	File No.	Dwg. No.	REV
B	B	Typical phase monitor installation	B
SCALE	None	DATE	1 OF 1
		5/6/2011	SHEET

This document is the sole property of Climacool Corp. Distribution of this document is forbidden without the written consent of Climacool Corp. Any reproduction or modification of this document may occur without notice.

Water Piping

As with any water system, it is important that the system be clean. The pipe work installer must remove weld scale, rust and contamination during pipe work fabrication. The system water piping must be flushed thoroughly with recommended alkaline flush or other chemicals that are compatible with 316 stainless steel, prior to making connections to the ClimaCool chiller. There are certain necessary components that should always be installed in both the chilled water and condenser water systems. (See Water Piping Configuration Figures 19 and 20 on page 16). Piping configurations on multiple modules may also be found on pages 15. All water piping must be installed in accordance with applicable codes and standards.

Temperature Sensor and Wells

ClimaCool provides four (4) temperature sensors and wells with each chiller system programmed by the CoolLogic Control System. They must be field installed a minimum of 36" but no more than 60" away from the bank and before the strainer, on the chilled water inlet, chilled water outlet, condenser water inlet and condenser water outlet. (See Water Piping Configuration on page 16). **Note: Sensors must be fully inserted into the well to obtain proper readings and must be 2 ½ pipe diameter minimum before or after an elbow. See Figures 14 and 15.**

Figure 14 - Temperature Sensors



Figure 15 - Flow Sensors (DPT)



Pressure Differential Flow Sensor

It is imperative that minimum and maximum water flow rates, as defined in the Operational Limitations tables on page 31, are not exceeded. To prevent operation of the chiller without sufficient water flow to the evaporator and condenser, it is required to install pressure differential flow sensors in both the chilled and condenser water circuits. Place one (1) on each side, downstream of the strainers on the inlet and outlet of a straight pipe, as close to the module as possible. **Do not put in an elbow on the outlet.** (See Water Piping Configurations on page 16). **Note: Evaporator and condenser sides both require sensors of equal pressure ranges.**

Pressure Taps

The installing contractor must provide access ports for connecting both the pressure differential flow sensors and pressure gauges for both the condenser and chilled water systems. A ¼" pressure tap is required on the inlet and the outlet of both water systems for a total of eight (8) taps. If a port is shared by the pressure differential flow sensor and the pressure gauge, it will require four (4) ½" taps. (See Water Piping Configurations on page 16).

Water Isolation Valves

It is recommended to provide bank water isolation valves for proper isolation and maintenance of the chiller, pump and strainer (See Water Piping Configurations on page 16).

Strainers – Minimum 60 Mesh Screen Required

ClimaCool chillers utilize brazed plate heat exchangers which are extremely sensitive to debris. **Therefore, it is mandatory that all condenser and chilled water systems include a strainer with a minimum of 60 mesh screen for proper filtration.** The strainers must be installed as shown in the Water Piping Configurations on page 16 and be in place at all times when the chiller(s) is/are in operation.

ClimaCool's warranty does not cover and does not apply to products which have defects or damages due to freezing of the water supply, an inadequate or interrupted water supply, corrosives or abrasives in the water supply, or improper or inadequate filtration or treatment of the water supply.

Chiller/Heater System Water Header Bypass

A bypass is required for any chilled water/evaporator, hot water/condenser (heating load) and source water side (geothermal, cooling tower or closed circuit cooler) with variable pumping. The bypass must be piped in such a way that the temperature and differential pressure sensors are still sensing active flow (See Water Piping Configuration

Water Piping

Figure 16 - Direct Return





Figure 17 - Reverse Return




Figures 19 and 20 on page 16). The purpose of the chiller/heater system bypass is to prevent deadheading of the pumps when all of the internal unit valves go closed as well as allow temperature and differential pressure sensors to sense active flow. The bypass should be sized for an absolute minimum of one module's worth of design flow. Please refer to selection submittals for design flow rates.

Modules can be designated for fixed bypass for heating, cooling and source flow, however, this limits the number of modules remaining for that duty. Also, with a module acting as a bypass increased wear of heat exchangers may be caused by abrasion from bypass flow.

ClimaCool offers two types of water header bypass kits, direct return (Figure 16) and reverse return (Figure 17). The bypass kits must be installed on each water source loop and controls are integrated with the CoolLogic software. Installation location can be found on page 16 – Water Piping Configuration.

This bypass can also be created with field supplied piping. The design piping must accommodate one module's worth of design flow, and be positioned so that the temperature and differential flow sensors sense active flow in the bypass mode. (See Figures 19 and 20 on page 16 - Water Piping Configuration). **The field supplied piped chiller/heater system bypass must be controlled by others.** There are system communication delays, polling and network conflicts that strictly prohibit the use of ClimaCool sensors and controls for control of field supplied bypasses or other field supplied items. Recommended method is to control via differential pressure or gpm flow meters across the chilled water/evaporator, hot water/condenser water systems.

Figure 18 - Typical Load Bypass Valve Arrangement



Load Side System Bypass (Air Handlers, Fan Coils, etc.)

A load system bypass is required for preventing pump deadheading, allowing active flow system sensing and preventing starving flow from the chiller/heater system. Examples of an acceptable load side system bypass are:

- Utilize a quantity of 3-way control valves on the largest loads farthest from the chiller/heater system.
- Field piping with a control valve to provide a bypass across the larger system loads when their 2-way valves go closed.

Please refer to Figure 18 for a typical load bypass valve arrangement. The load side system bypass should be sized for an absolute minimum of one module's worth of design flow. (Please refer to selection submittals for design flow rates). A minimum of (6) six gallons per nominal system ton are also required to maintain proper system thermal inertia. This is to avoid short cycling of compressors in the chiller/heater system as well as prevent nuisance alarms.

Water Piping Configurations

Figure 19 - Field Piping Direct Return





Figure 20 - Field Piping Reverse Return



Notes:

1. Figures 19 and 20 are required piping for proper water regulation and distribution through ClimaCool modular chillers.
2. Module order and incoming/outgoing water flow as shown in both Figure 19 and 20 can be set up as either a left-to-right or right-to-left configuration.
3. Condenser hydronic circuit shown. Piping configurations are similar for the chilled water hydronic circuit.
4. For condenser/heating and chilled water (evaporator) inlet/outlet location dimensions, refer to page 4 - Dimension Data.
5. A pressure differential flow sensor is a required safety device for ClimaCool modular chillers on the chilled and condenser/heating water circuits.
6. A strainer with a minimum of 60 mesh stainless steel screen is a required safety to protect the brazed plate heat exchangers on both chilled and condenser/heating water sides of the system.
7. Maximum water flow rates for both evaporator and condenser/heating water header systems for 30, 50 and 70 ton modules in one bank is 1,000 gpm.
8. Maximum water flow rates for both evaporator and condenser/heating water header systems for 85 ton modules in one bank is 2,400 gpm.
9. Bypass is **mandatory** for systems utilizing motorized valves.
10. Header bypass valve may be installed at either end of bank.
11. For over seven (7) modules, please consult the factory.

Hydronic Refrigeration

Figure 21- Condenser Hydronic Circuit






Figure 22 - Chilled Water Circuit



Note: Figure 21 and 22 depict hydronic piping in each ClimaCool chiller module and are shown with water isolation valves.


Part-Load Performance Advantage

Figure 23




ClimaCool modular chillers employ reliable and highly efficient brazed plate heat exchangers. These compact exchangers are true dual-circuit heat exchangers in which each water channel is flanked by two refrigerant circuits. This design gives maximum performance, even at part-load.

Of course, full performance is attained when the dual-circuit heat exchangers are run to full-load (i.e. with both refrigerant circuits).




If circuit 1 is cut, the unique design allows each water channel to remain in contact with refrigerant circuit 2, providing optimum heat transfer.

Refrigerant Circuit 2 Only



The same results are achieved if circuit 1 is ran and circuit 2 cut out; optimum heat transfer, even at part-load.

Refrigerant Circuit 1 Only



Filling the Water System

It is imperative that the water systems are free from debris prior to initial operation. See Water Treatment for a comprehensive list of precautions on page 20.

Filling, Purging and Leak Testing the System

After the water systems have been properly installed, visually inspect all joints for tightness. If the chiller is to be installed in an existing system, the cleanliness of the existing system can be judged from the operating conditions of the present machines. The cooling tower in particular, should be inspected and cleaned, if required. It is good practice to flush and, ideally, to acid wash the existing system **before** connecting a new chiller.

The following method is recommended to fill and leak check the water system for modules **WITH** Water Isolation Valves:

1. Close all water isolation valves inside each module which isolate the individual heat exchangers.
2. Ensure that all drain valves are closed and that all water main isolation valves are opened.
3. The system should be filled with clean water sent through the strainers and the system checked for leaks.
4. Once the main water lines and the chiller headers are filled with clean water, purge and repeat the filling process at least three times.
5. All modules are equipped with $\frac{3}{4}$ " fill and flush valves with lines teed into the inlet and outlet connections into and out of each heat exchanger. Ensure these $\frac{3}{4}$ " valves are **CLOSED**.
6. Open the water isolation valves inside each modular chiller and repeat the filling process, this time also checking for leaks inside each module.
7. Following the final filling and leak checking procedure, air should be purged from the system.

The following system is recommended to fill and leak check the water system for modules **WITHOUT** Water Isolation Valves:

1. Ensure that all drain valves are closed.
2. All modules are equipped with $\frac{3}{4}$ " fill and flush valves with lines teed into the inlet and outlet connections into and out of each heat exchanger. Ensure these $\frac{3}{4}$ " valves are **CLOSED**.
3. The system should be filled with clean water sent through the strainers and the system checked for leaks.
4. Once the main water lines and the chiller headers are filled with clean water, purge and repeat the filling process at least three times.
5. Following the final filling and leak checking procedure, air should be purged from the system.

Cleaning the System

The following method is recommended to properly clean the water systems:

1. Before cleaning the system, install a temporary bypass line between the main supply and return water headers of both chilled and condenser water systems when possible. Open the main header bypass lines to divert the initial water flow around the module heat exchangers until you are confident the circulating water is mostly pure.
2. Provided main header bypass lines are installed, close all water isolation valves inside all modular chillers equipped with manual or automatic water isolation valves. If the modules are **NOT** equipped with water isolation valves, we recommend installing 3-way main header bypass valves so the initial water flow bypasses all module heat exchangers.
3. It is mandatory to run the pumps with the strainers in place (see Starting the Pumps section below for proper pump startup). All external hydronic branches should be open to all devices in the system.
4. Pressure drop across the strainer must be observed and as pressure change reaches 50% of the initial read, strainers must be isolated and cleaned.
5. Open all water isolation valves inside each module equipped with manual or automatic water isolation valves (see step 6 for modules **NOT** equipped with water valves). If bypass lines are not installed (described in step 1) it is recommended to drain out the initial fill of water to help flush out debris. Close off the main header bypass lines referred to in step 1 and open the flow to the main water headers. Repeat steps 3 and 4 until there is no more debris being collected by the strainers.
6. If bypass lines are not installed (described in step 1) and the modules are **NOT** equipped with water isolation valves, it is recommended to drain out the initial fill of water to help flush out debris. Remove and clean the strainers before refilling and purging the system again. Repeat steps 3 and 4 until there is no more debris being collected by the strainers.

Starting the Pumps

Follow the manufacturer's recommendations when starting the pumps for the first time. The system should be checked for leaks and air purged with the pumps in operation. The pressure drop across the heat exchangers will give a good indication of flow through the system (See Condenser and Evaporator Water Pressure Drop Charts on page 22). This should be immediately checked against the expected pressure drop for the flow rate required. **If the pressure drop begins to fall and the flow rate is falling, this could indicate the need to clean the strainers.**

Water Treatment

Water quality is of the utmost importance for the proper care and maintenance of the modular chiller system.

Proper water treatment is a specialized industry and it is recommended to consult an expert in this field to analyze the water for compliance with the water quality parameters listed in Table 1. The materials exposed to the water are type 316 stainless steel, pure copper and carbon steel. Other materials may exist external to the ClimaCool chiller. It is the user's responsibility to ensure these materials are compatible with the treated water. Regular treatment of the water will increase longevity of your system.

Failure to provide adequate filtration or treatment of evaporator and condenser water will void the ClimaCool module's warranty.

Heavy-Contaminated Water

In such instances whereby the particulates in the water are excessive, it is recommended to install an intermediate plate and frame heat exchanger to isolate the ClimaCool chiller from the building water system.

Cooling Tower

The cooling tower should be located away from sources of external contaminants such as trees, dust or grass cuttings. Insect infiltration can be reduced by eliminating lights near the tower. A periodic visual inspection of the tower system should be made and contaminants removed as required.

Table 1 - Water Quality Parameters

WATER CONTAINING	CONCENTRATION
Ammonia	Less than 2.0 mg/l
CaCO ₃ Alkalinity	30 - 500 mg/l
CaCO ₃ Hardness	30 - 500 mg/l
Chlorides	Less than 200 mg/l
Dissolved Solids	Less than 1000 mg/l
Iron	Less than 5.0 mg/l
Manganese	Less than 0.4 mg/l
Nitrate	Less than 100 mg/l
pH	7.0 - 9.0
Sulphate	Less Than 200 mg/l

CAUTION/ATTENTION	
Excessive Chlorine, undissolved solids and other improper water conditions WILL DAMAGE the internal heat exchanger & WILL VOID YOUR WARRANTY!	Chlore excessive, solides non dissous et les autres impropres conditions de l'eau, ENDOMMAGERA l'échangeur de chaleur interne et ANNULERA VOTRE GARANTIE!

Water Temperature Requirements


Condenser Water Temperature

The condensers are designed to operate most efficiently at lower entering water temperatures for lower power consumption. The expansion valve, however, relies on the pressure difference across the valve to drive the liquid refrigerant through. It is necessary to maintain a minimum pressure differential across the thermal expansion valve (equivalent to a 30°F difference between saturated liquid temperature in the condenser and saturated vapor temperature in the evaporator) to avoid loss of efficiency and system performance. This pressure differential is most commonly ensured by cycling the fans on the cooling tower to maintain the entering condenser water temperature above the minimum temperature of 60°F. An alternate method to maintain the minimum entering condenser water temperature above 60°F is to employ a bypass arrangement as shown in Figure 24 below. This valve is an automatic 3-way bypass valve, which senses the temperature of the mixed water entering the condenser. If this mixed water temperature falls below 60°F the valve will re-circulate the leaving condenser water and mix it into the entering condenser water stream (bypassing the cooling tower). The full range of entering condenser water is 60°F to 95°F for standard applications and maximum leaving hot water temperature of 135°F for high temperature applications. For entering water less than 60°F refer to Motorized Water Isolation Valves under Options and Accessories on page 41.

Chilled Water Temperature



Modules are designed for a leaving water temperature range from 40°F to 62°F. All cataloged modules can operate safely in this range without the need of special controls or glycol additives. Leaving water temperatures below 40°F can result in evaporator suction temperatures below the freezing point of water. Therefore, a glycol solution additive is required that will protect the evaporator from freeze ups at lower operating suction temperatures. The full range of leaving chiller fluid using glycol is 20°F to 62°F.

Figure 24 - Condenser Water System




Note: Only required for equipment without motorized condenser valves.


Condenser and Evaporator Water Pressure Drop Charts - 030, 050, 070, 085




Glycol Performance Adjustment Factors Charts




Note: Correction factors shown above are to be applied to Std. Product Data @ ARI 550/590 44°F. Leaving Chilled Water / 85°F Entering / 95°F Leaving Conditioned Water.



Note: Correction factors shown above are to be applied to Std. Product Data chiller pressure drop curves for straight water.



Note: Correction factors shown above are to be applied to Std. Product Data @ ARI 550/590 44°F. Leaving Chilled Water / 85°F Entering / 95°F Leaving Conditioned Water.



Note: Correction factors shown above are to be applied to Std. Product Data chiller pressure drop curves for straight water.

Glycol Performance Adjustment Factors Charts




Table 2 - Performance Adjustment Factors vs. Altitude vs. Chiller Temperature Drop

Chiller	Sea Level			2000 ft.			4000 ft.			6000 ft.		
	Capacity Multiplier	Flow gpm Multiplier	kW Power Multiplier	Capacity Multiplier	Flow gpm Multiplier	kW Power Multiplier	Capacity Multiplier	Flow gpm Multiplier	kW Power Multiplier	Capacity Multiplier	Flow gpm Multiplier	kW Power Multiplier
8	0.995	1.246	0.998	0.990	1.244	1.003	0.986	1.238	1.006	0.980	1.232	1.012
10	1.000	1.000	1.000	0.993	0.997	1.004	0.989	0.990	1.007	0.983	0.996	1.014
12	1.005	0.834	1.001	0.996	0.831	1.004	0.992	0.826	1.008	0.986	0.821	1.016
14	1.010	0.716	1.001	0.998	0.714	1.005	0.994	0.709	1.009	0.989	0.704	1.018

Pre-Startup

All startups must be performed by ClimaCool factory trained personnel. Prior to chiller startup, there are certain essential checks which must be completed. Failure to carry out these checks could result in damage to the chiller voiding the modules warranty.

Electrical

It is imperative to turn off the main electrical power supply and follow proper lock-out/tag-out procedures prior to servicing any of the chiller's electrical components. **The following procedures can be performed only after the electrical power is confirmed to be off:**

1. The installation must be inspected and approved by the respective agent and be in compliance with all local and national electrical codes.
2. **Check and tighten all electrical terminal connections on each module as required.** Utilize any lock-out/tag-out procedures required for your project location when performing this operation. If no procedure exists, take all precautions necessary to prevent the power from being turned on. **A systematic tightening of all terminals inside the electrical control panel on each module should be carried out.** This will include the compressor motor terminals, which would require removal of the compressor terminal cover. Check connections at each safety and every termination in the panel.
3. Verify that a separate 115 volt power supply is used to power the CoolLogic Control System. Field connections are simplified requiring only a two conductor shielded cable daisy chain from the Master Control Panel to the modules. These control wires should be two-conductor shielded having #18 AWG minimum up to 50 feet, #16 AWG minimum up to 100 feet, rated at 60°C minimum. All field wiring must be identified (tagged). Refer to Power Distribution Drawing on page 53.
4. All field connections should be checked for tightness.
5. Check all fuses for proper sizing as indicated on the chiller data plate and/or the electrical diagram on the inside door of the electrical panel.
6. Verify proper operation of the **mandatory** field installed pressure differential flow sensor or switch.
7. On 208/230v units, confirm transformers are properly tapped for the measured incoming power supply.
8. Verify proper installation of the **mandatory factory provided, field installed voltage/phase monitor.**

Refrigeration

1. Refrigerant piping and components should be inspected for damage.
2. Place refrigerant gauges on the discharge and suction access ports of each refrigerant circuit to ensure a refrigerant charge is present. Leave the gauges on for compressor rotation check.
3. Confirm the settings on all pressure sensors.

Water System

1. Confirm that leak testing has been carried out.
2. Confirm that the system is clean.
3. Confirm that necessary water treatment systems are in place with both the evaporator and condenser water systems.
4. Confirm that both the chilled water and condenser water circulating pumps are operational and water is flowing through both exchangers.
5. Shut the entering water valve and blow out some water to check for particles or coloration from suspended particles. Record the pressure differential across the chiller and condenser heat exchangers, measured at the pete's ports at each module.
6. Confirm correct water flow rates through the condenser and evaporator. Acquire the design parameters for the chiller bank from the ClimaCool Selection Program data (available from the local representative). Compare the measured differential pressures from step 5 above with the predicted flow rates to ensure proper correlation to the flow results.
7. Verify proper installation of the mandatory factory provided, field installed temperature sensors and wells (**sensor should be fully inserted in the well**) and verify calibration of sensors read through the CoolLogic Control System.
8. Confirm installation of **mandatory field installed condenser and chilled water strainers with a minimum of 60 mesh screens.**

CAUTION/ATTENTION	
Use only copper conductors for field installed wiring. Unit terminals are not designed to accept other types of conductors.	Utilisez uniquement des conducteurs en cuivre pour le câblage. Bornes de l'unité ne sont pas conçus pour accepter d'autres types de conducteurs.

WARNING/AVERTISSEMENT	
Disconnect power supply (ies) before servicing. Refer servicing to qualified service personnel. Electric shock hazard. May result in injury or death!	 Debrancher avant d'entreprendre le dépannage de l'appareil. Consulter un réparateur qualifié pour le dépannage. Risque de choc électrique. Résultat de mal dans dommages ou la mort!
CAUTION/ATTENTION	
Unit to be serviced by qualified personnel only. Refrigerant system under pressure. Relieve pressure before using torch. Recover refrigerant and store or dispose of properly.	 Conifer la maintenance à un technicien qualifié. Le système frigorifique sous pression. Décompresser avant d'exposer à la flamme. Récupérer le frigorigène et le stocker ou le détruire correctement.

Project Name:	Date:
Address/Phone:	

	YES	NO
1. Are modules connected properly per Codes and ClimaCool Installation Manual? (Installation, Operation & Maintenance (IOM) Manual is available at www.climacoolcorp.com)	<input type="checkbox"/>	<input type="checkbox"/>
2. Is there a minimum of 60 mesh strainer on condenser and evaporator inlet water? (Fill water to chiller being sure to pass through a minimum of 60 mesh strainer.)	<input type="checkbox"/>	<input type="checkbox"/>
3. Is condenser water system filled and <u>flushed</u> ? (See "Filling the Water System" in ClimaCool IOM.)	<input type="checkbox"/>	<input type="checkbox"/>
4. Is Chilled water system filled, flushed and all air purged from system? (All air must be purged from system prior to startup. See "Filling the Water System" in ClimaCool IOM.)	<input type="checkbox"/>	<input type="checkbox"/>
5. Are all pumps tested and operational?	<input type="checkbox"/>	<input type="checkbox"/>
6. Are required GPM's (verified by pressure differential) supplied to the Chilled water side? (See project specifications or selection and performance sheets available from ClimaCool Sales Rep.)	<input type="checkbox"/>	<input type="checkbox"/>
7. Are required GPM's/Pressure differential being supplied to the Condenser? (See project specifications or selection and performance sheets available from ClimaCool Sales Rep.)	<input type="checkbox"/>	<input type="checkbox"/>
8. Are the pressure differential flow sensors properly installed and wired to the CoolLogic controller?	<input type="checkbox"/>	<input type="checkbox"/>
9. Have all chiller coupling connections been leak tested?	<input type="checkbox"/>	<input type="checkbox"/>
10. Is water presently circulating through chiller?	<input type="checkbox"/>	<input type="checkbox"/>
11. Verified that temperature sensors and voltage/phase monitor have been installed?	<input type="checkbox"/>	<input type="checkbox"/>
12. Verified power supply agrees with chiller nameplate?	<input type="checkbox"/>	<input type="checkbox"/>
13. Is power and communication wiring complete to each module?	<input type="checkbox"/>	<input type="checkbox"/>
14. Verified that wiring and devices meet with approved electrical submittal drawings?	<input type="checkbox"/>	<input type="checkbox"/>
15. Is required load available to run multiple compressors at startup?	<input type="checkbox"/>	<input type="checkbox"/>
16. Is control functional to maintain condenser water temperature? (This includes maintaining "minimum" inlet temperature. See "Operational Limitations" in IOM.)	<input type="checkbox"/>	<input type="checkbox"/>
17. Is water header bypass installed at the chiller? <input type="checkbox"/> ClimaCool Provided? <input type="checkbox"/> Field Provided? (Check one)		

If you checked "No" to any question above, provide the line reference number and the date of scheduled completion below. Please note **all conditions must be complete prior to the startup date.**

*This form must be completed and submitted to ClimaCool Corp. a minimum of **three (3) weeks** prior to final scheduling of any startup. **Note: If any of the above items are not complete at time of startup, back charges will be assessed for additional costs.**

Contractor Name:	
Address:	(Authorized Signature)
Phone:	Date:

Startup

All startups must be performed by ClimaCool factory trained personnel.

1. Review all items are complete from the Pre-Startup Check List.
2. Cross reference model number with submittal sheet to verify that the units are the correct model type and voltage requirements.
3. Verify the location and wiring connections of all main header temperature sensors (should be a minimum of 36" but no more than 60" from the bank). Confirm that all sensors are **FULLY INSERTED** into their sensor wells and wired back to the correct terminals in the Master Control Panel.
4. Verify the location and ports for all water differential pressure sensors used for flow detection ((+) port piped to the inlet headers and the (-) ports piped to the outlet headers).
 - Verify the correct wiring using the +5VDC power supply to the differential sensor inputs.
 - Verify the correct output wiring from the differential sensors back to the master controller universal input (UI) channels 8 and 11. Confirm inputs 8 & 11 jumpers are set for 'volts'. **Note:** The differential sensor ports should **NOT** be piped to a location which includes strainer pressure drops.
5. Verify that all header inlets (condenser and evaporator) include strainer assemblies equipped with 60 mesh screens.
6. Inspect all refrigerant piping for oil leaks which may have occurred during shipment which might indicate a refrigerant leak. Check the high pressure cutout setting of the pressure controls. The setting should be 385 psig cutout for all UCW models, and 585 psig for all UCH models.
7. Verify the location and settings of the phase loss monitor. It should be in a location to sense the voltage condition in the main, high voltage panel which feeds high voltage to each module independently. (Review Electrical Connection of IO&M on page 10). Verify the low voltage output wiring from the phase loss monitor (terminals 4 and 5) back to the main CoolLogic controller, input channel 12.
8. Determine if the chiller modules are equipped with motorized water isolation valves. If so, verify the settings of the motorized valves auxiliary switch dial settings, to ensure they close near:
 - 15% for source valve (condenser) and for load side (evaporator or heat)
9. Confirm that the main water pumps are driven by VFD's, and that all VFD's are controlling the pump speeds to produce a nominal differential pressure drop across the chiller bank headers, measured precisely at the differential pressure sensor locations in step 4 above. Nominal differential pressure ranges are from 3 to 10 psid.
10. Confirm the jumper locations for all master controller and module controllers as shown on the wiring diagrams provided on the inside electrical door panels.
 - Set the rotary switches for the MAC Address of the master controller to be "01."
 - Set the rotary switches for the module controllers to be "02" for module #1, "03" for module #2, and so on.
11. Tighten every screw and lug connection inside the CoolLogic master control panel and inside each module control panel high voltage section. Check auxiliary contacts on contactors ensure #1 auxiliary is wired on the #1 contactor. Open up the compressor junction box located on the front of each compressor and verify main electrical terminal lug tightness and the low voltage wires on protection module.
12. Verify the communication cable wiring to ensure it is 18 AWG, simple two conductor shielded cable and that the wiring is alone inside solid conduit between the master control panel and the first module control panel. Verify the cable's outer jacket is not stripped more than one inch. If so, the wires may have become untwisted, causing signal reflections. Confirm the wires are connected correctly to the terminal blocks at the master and each module as follows:
 - Black wire to **Net-**
 - White wire to **Net +**
 - Shield wire to **Shield**Verify that the shield part of the wires continues the daisy chain connection through to the last module but, that this shield is **NOT** connected to a terminal lug inside any module.
13. Power-up the master control panel and download the appropriate clipping file into the master controller, following instructions.
14. Power up each module control panel, turn OFF the two toggle switches located on the inside bottom of the low voltage side of the module electrical panel. Download the appropriate clipping file into the module controllers, following instructions.
15. Check for proper line or high voltage values at each module input power block, and the 24 VAC low voltage values for correctness (+/- 10% of nominal values).
16. On 208/230V units, confirm transformer(s) are properly tapped for the measured incoming power supply.
17. Use refrigerant gauge set suitable for the high pressure R-410A, and hook up to the suction and discharge ports of each module's compressor stages separately. Bump start the compressors either by depressing the contactor manually, or by using the manual run commands from the Master Control Panel, (found in the FN 7, or the service menu). Bump the compressor only for 1-2 seconds to ensure the correct rotation of the scroll compressors (indicated by a rising highside pressure and a falling suction pressure).

Startup

18. Verify proper communications from each module back to the master controller using the “STATUS” menu, then indexing down to the desired compressor data screen.
 - If the compressor data parameters all read “o,” then communications are not yet established, and communications cable troubleshooting is required.
 - When all compressor data parameters read actual values which agree with the refrigerant gauge set and refrigerant line temperatures, then it is safe to assume that communications are established.
19. Set up the master controller parameters according to the specific job submittal sheets.
 - All parameters can be found in the FN 2 menu (setup), FN 6 menu (module factory settings), FN 7 menu (service), FN 8 menu (master factory settings).
 - It is imperative to access EVERY MENU and EVERY PARAMETER to ensure all settings are appropriate.
20. Set up the Building Automation System (BAS) interface parameters (as required) using the FN 0 menu (network number selection, IP addressing), FN 4 menu (device instances).

(typically 44^{oF} leaving chilled water temperature). If superheat is low, this may indicate that the expansion valve is overfeeding. To adjust the expansion valves, turn the adjustment stem clockwise. This will cause the superheat to rise. Wait five minutes before checking the results of this adjustment. Repeat until the desired superheat is achieved.

Once adjusted, also check the discharge gas superheat (DGSH) to confirm reading is not less than 50°F and the discharge line temperature is not more than 220°F. To check discharge gas superheat, first obtain the saturated condensing temperature by converting the discharge pressure to saturated refrigerant temperature using a pressure temperature chart. Next, measure the discharge line temperature 6 to 10 inches from the compressor. Subtract the saturated condensing temperature from the discharge line temperature to find the discharge gas superheat. If the DGSH is below 50°F, liquid refrigerant is still present in the suction gas vapor returning to the compressor. The TXV will require additional clockwise adjustment to raise the discharge gas superheat into the acceptable range.

Adjusting Unit Charge and Thermal Expansion Valves Using Subcooling and Superheat Method


Due to varying installation conditions/applications and to optimize performance, proper refrigerant charge and thermal expansion valve (TXV) adjustment must be confirmed.

After checking compressor rotation, choose a circuit to be tested first. Connect test equipment to monitor the suction line and liquid line temperatures simultaneously. Place a manifold gauge set on the suction line and liquid line then start the compressor. As long as the suction pressure is high enough to prevent the low pressure switch from tripping, run the compressor for five minutes.

Verify proper subcooling. This is accomplished by subtracting the liquid line temperature from the saturated condensing temperature. The saturated condensing temperature is found by converting the liquid line pressure reading on the manifold gauge to the related temperature. The normal subcooling temperature range at the condenser is 5-15°F, BUT for total accuracy please follow the charge recommendations found in the selection program. If subcooling is too low, then refrigerant must be added to the system. Add charge and wait five minutes before checking results. If subcooling is too high, then refrigerant must be removed from the system.

Verify proper superheat by subtracting the saturated evaporative temperature from the suction line temperature. The saturated evaporative temperature is found by converting the suction pressure reading on the manifold gauge to the related temperature. The proper superheat temperature range is 6-18°F at normal operating conditions

Subcooling & Superheat Flow Chart



Caution: Do not charge to achieve subcooling temperature when the expansion valve is overfeeding. If the expansion valve is overfeeding, readings may still indicate low subcooling and low superheat, but circuit may not be undercharged.

Startup Documentation

All startup paperwork and documentation must be submitted to ClimaCool. Future warranty claims cannot be processed without a completed Startup and Warranty Registration form on file (See page 30).

Note: Electronic version of the Startup forms available on www.climacoolcorp.com on the Service page.

Water Testing

Extract three water samples from each water loop, Hot Water/Condenser, Chilled Water/Evaporator using the bottles provided (three (3) bags; each bag containing three (3) bottles) from the Water Sample test kit. Confirm that

the sample bottles are filled to the top leaving no air in the bottles. All the sample bottles must have labels completed per instructions included with the bottles. Ship the bottles immediately to the appropriate water testing laboratory per the instructions.

Startup and Warranty Registration Form (Water-Cooled UCW/H)

Sign, date and E-mail to: technicalsupport@climacoolcorp.com or
 Fax: 405.815.3052 Attn: Technical Support

Ambient Temp: _____ Page 1 of 1

Project Name: _____
 Address: _____
 City/State/Zip: _____
 Start-up Date: _____

Contractor Name: _____
 Address: _____
 City/State/Zip: _____
 Phone No.: _____

Module

Model No.: _____
 Serial No.: _____
 Chiller No.: _____ Bank No.: _____

Compressor

Model No.: _____
 Serial No. 1: _____
 Serial No. 2: _____

Bank Water Pressures Entering / Leaving

Evaporator: _____ / _____ Δ P _____
 Condenser: _____ / _____ Δ P _____

Water Samples Taken (Mark "X")

Evaporator: Yes N/A
 Condenser: Yes N/A
 Yes

"Flow devices" shut off chiller below 40% of flow for Evaporator and 25% for Condenser:

**For initial MANDATORY water samples, bottles are provided.
 Follow instructions on label and mail the same day sample is taken.**

- ▶ All wiring terminations in module panel, safeties and compressors tightened: Yes No
- ▶ Rotation of scroll compressor is correct: Yes No

Voltage / Ground

L1 _____ L2 _____ L3 _____
 Low Voltage (24V): _____

Phase / Phase

L1/L2 _____ L2/L3 _____ L1/L3 _____

Compressor Circuit #1

Amperage: L1 _____ L2 _____ L3 _____
 Sight Glass Oil Level: _____
 Suction Pressure: _____
 Suction Temperature: _____
 Compressor Superheat: _____
 Discharge Pressure: _____
 Discharge Line Temperature (F): _____
 Discharge Gas Superheat (F): _____
 Liquid Line Temperature: _____
 Liquid Subcooling: _____
 Evaporator Entering Water Temperature: _____
 Evaporator Leaving Water Temperature: _____
 Condenser Entering Water Temperature: _____
 Condenser Leaving Water Temperature: _____
 Evaporator Pressure Differential: _____
 Condenser Pressure Differential: _____

Compressor Circuit #2

Amperage: L1 _____ L2 _____ L3 _____
 Sight Glass Oil Level: _____
 Suction Pressure: _____
 Suction Temperature: _____
 Compressor Superheat: _____
 Discharge Pressure: _____
 Discharge Line Temperature (F): _____
 Discharge Gas Superheat (F): _____
 Liquid Line Temperature: _____
 Liquid Subcooling: _____
 Evaporator Entering Water Temperature: _____
 Evaporator Leaving Water Temperature: _____
 Condenser Entering Water Temperature: _____
 Condenser Leaving Water Temperature: _____
 Software Version: _____

▶ Verify Safety Setting Limits:

Low Temp: High Pressure: Low Pressure:

▶ Verify Safety Setting Limits:

Low Temp: High Pressure: Low Pressure:

Rep Signature: _____

Print Name: _____

E-Signature: Check Box (Authorized Signature)

Chiller Operation and Maintenance

Pressure and Temperature Log

A log of temperatures and pressures should be taken regularly. Periodically conduct a visual inspection of the chiller to identify problems before they reach the point of failure. As with any mechanical system, it is necessary to conduct a series of checks to confirm correct operation of the chiller.

Maintaining a Daily Log

Date	Chiller No.							Technician								
	SUN	MON	TUE	WED	THU	FRI	SAT									
Chilled Water Entering Temperature																
Chilled Water Leaving Temperature																
Condenser Water Entering Temperature																
Condenser Water Leaving Temperature																
Chilled Water Pressure Drop																
Condenser Water Pressure Drop																
Faults: Note By Module Number																

Daily

- A daily operational log should be kept.
- Perform visual inspection.
- Record entering and leaving chiller water and condenser water temperatures and pressures.
- Properly document all data taken.
- Note any problems that may exist and immediately plan for further investigation. If repair is necessary, schedule for the earliest possible date.

Weekly

- Review daily log from previous week.
- Perform visual inspection.
- Properly document all data taken.
- Note any problems that may exist and immediately plan for further investigation. If repair is necessary, schedule for the earliest possible date.

Quarterly

- Check Master Control Panel operating parameters and set points.
- Check temperature drop/rise on each individual heat exchanger. *
- Check compressor oil level.
- Check compressor oil color.
- Check water flow rates and pressure drops across evaporator and condenser heat exchangers.

- Properly document all data taken.
 - Check all electrical connections for tightness.
- * The temperature drop/rise on a fully loaded (both compressors) heat exchanger is generally 10°F. If only one compressor is running the temperature drop/rise will be approximately 5°F. Some projects are designed to have a higher or lower temperature drop on either the evaporator or the condenser depending on application. Consult the bank performance sheet for your specific project for these values. If the temperature drop/rise is greater than the design, your heat exchanger may need to be back flushed or the strainer may need to be cleaned.

Annual

- Back flush all heat exchangers. If fouling is suspected use only ClimaCool recommended de-scalers (See Chemical Clean In Place Washing on page 32).
- Remove and clean all waterside strainers.
- Manually operate all waterside isolation valves, if provided, on each module.
- Check all electrical connections for tightness.
- Perform leak check on all refrigerant circuits.
- Check all header piping couplings for tightness.
- Check oil level and color on each compressor.
- Check and test all refrigerant safeties for proper operation.
- Check all peripheral systems for proper operation.
- Check and test CoolLogic Control System.
- Verify set points, sensors and general control configuration.
- Properly document all data taken.



Heat Exchangers

Draining

When performing standard maintenance procedures such as flushing a heat exchanger, it will be necessary to close off a section of a module. This can easily be done if factory mounted water isolation valves are provided. Access to a floor drain is helpful when performing standard maintenance procedures.

Back Washing

It may become evident from the recorded weekly log data that the performance of the chiller is gradually degrading. This could be due to a buildup of debris or sludge obstructing the free passage of flow through the heat exchangers. This debris can be removed by a back washing process which involves the introduction of a forced, violent backwards flow through the heat exchanger using a carefully formulated flushing solution. To be effective, this back flow should be slightly higher than the normal flow, and in the opposite direction. The difficulties and practicality of this method depend on the back wash pumping system itself. Another method is to back flush each heat exchanger using city water as opposed to system water (see Figure 25 – City Water Cleaning Arrangement on page 33). The back washing procedure is accomplished by isolating each individual heat exchanger and introducing the city water using a connection hose to the ¾” service port to flow in an opposite direction from the normal heat exchanger flow direction. On the opposite ¾” service port, connect a drain hose to run to a suitable floor drain. Continue the back flow until all debris is removed. **Warning: Water valves must be re-opened after flushing is complete.**

Chemical Clean In Place Washing Without Water Isolation Valves

Chemical Clean in place washing will typically provide the best debris removal, even from severely clogged heat exchangers. In order to clean the heat exchangers for modules **WITHOUT** water isolation valves, it will be necessary to mechanically and electrically isolate each module separately from the bank of modules. The rest of the chiller modules will need to be disabled during this cleaning procedure as the flow through the main bank header will be interrupted. The cleaning tank, pump and pump strainer should be arranged in the manner shown in Figure 26 - In Place Cleaning Arrangement (page 33). The flow of the cleaning is arranged in the opposite flow to the normal operational direction. Connection points are provided using the ¾” service ports at each heat exchanger. The cleaning solution used can be either a detergent or hot water to remove particles and simple cleaning. If correct water treatment has been implemented, this should provide adequate cleaning for most situations. The solution can be pumped through the heat exchangers and allowed to

“soak” for a time and then pumped again. Upon successful cleaning of a module, proceed to isolate a second module separately from the bank to repeat the cleaning process.

Chemical Clean In Place Washing With Water Isolation Valves

Chemical Clean in place washing will typically provide the best debris removal, even from severely clogged heat exchangers. It is only necessary to mechanically and electrically isolate one module at a time. The rest of the chiller modules can continue to operate to satisfy the required cooling load. The cleaning tank, pump and pump strainer should be arranged in the manner shown in Figure 26 - In Place Cleaning Arrangement on page 33. The flow of the cleaning is arranged in the opposite flow to the normal operational direction. Connection points are provided using the ¾” service ports at each heat exchanger. The cleaning solution used can be either a detergent or hot water to remove particles and simple cleaning. If correct water treatment has been implemented, this should provide adequate cleaning for most situations. The solution can be pumped through the heat exchangers and allowed to soak for a time and then pumped again.

If it is required to remove carbonates, then an acidic wash should be used. A 2% solution of phosphoric or sulfamic acids in pure water are generally acceptable. These acid solutions should only be allowed to circulate within the heat exchanger for 10 to 15 minutes, followed by a thorough pure water flush for 10 to 15 minutes. **Hydrochloric or sulfuric acids must not be used.** In any case, consult the chemical supplier to establish the correct formulation and handling process. The materials exposed to the wash are stated on page 20 – Water Treatment.

Once the washing is complete, the solution should be flushed out completely by pumping clean, fresh water through the chiller. To achieve a reasonable level of dilution, it may be required to change the water several times. After cleaning, the water quality and water treatment should be confirmed.

Cleaning Arrangement

Figure 25 - City Water Cleaning Arrangement





Figure 26 - In Place Cleaning Arrangement



Notes:

1. When backwashing, be sure to flush in opposite direction of flow.
2. Be sure to open all manual valves before unit is put back into operation.

Operational Limitations

Voltage Limitations		
The following voltage limitations are absolute and operation beyond these limitations may cause serious damage to the compressor.		
Nominal Voltage	Minimum Voltage	Maximum Voltage
208/230/3/60	187	253
460/3/60	414	506
575/3/60	518	632

Water Flow Data	UCW/H 030	UCW/H 050	UCW/H 070	UCW/H 085
Minimum Evaporator Water Flow (gpm) ¹	40	65	85	100
Maximum Evaporator Water Flow (gpm) ¹	165	250	250	350
Minimum Condenser Water Flow (gpm) ¹	30	50	70	85
Maximum Condenser Water Flow (gpm) ¹	165	250	250	485
Minimum Leaving Evaporator Water Temperature (No Glycol)(°F)	40	40	40	40
Minimum Leaving Evaporator Water Temperature (with Glycol)(°F)	20	20	20	20
Maximum Leaving Evaporator Water Temperature (°F)	62	62	62	62
Minimum Evaporator Water Differential Temperature (°F)	5	5.4	5.9	4.5
Maximum Evaporator Water Differential Temperature (°F)	20	20	20	20
Minimum Entering Condenser Water Temperature (°F)	60	60	60	60
Minimum Condenser Water Differential Temperature (°F)	6.5	6.9	7.2	5.5
Maximum Condenser Water Differential Temperature (°F)	30	30	30	30
Water Flow Data	UCW 030	UCW 050	UCW 070	UCW 085
Maximum Leaving Condenser Water Temperature (°F)	110	110	110	110
Water Flow Data	UCH 030	UCH 050	UCH 070	UCH 085
Maximum Leaving Condenser Water Temperature (°F)	135	135	135	135
Equipment Room Data	UCW/H 030	UCW/H 050	UCW/H 070	UCW/H 085
Minimum Equipment Room Ambient Temperature (°F)	55	55	55	55
Maximum Equipment Room Ambient Temperature (°F)	105	105	105	105
Compressor Operating Limitations	30, 50, 70 Tons		85 Tons	
	UCW	UCH	UCW	UCH
Maximum Compression Ratio	5.0:1	5.7:1	4.8:1	5.7:1
Minimum Operating Pressure Differential (psi)	85	85	85	85
Maximum Operating Pressure Differential (psi)	290	475	290	475
Minimum Discharge Pressure (psig)	215	215	215	215
Maximum Discharge Pressure (psig)	395	590	395	590
Minimum Suction Pressure (No Glycol)(psig)	90	90	90	90
Minimum Suction Pressure (With Glycol)(psig)	70	70	70	70
Maximum Suction Pressure (psig)	155	155	155	155
Maximum Discharge Temperature (°F)	225	265	225	265
Minimum Subcooling (°F)	5	5	5	5
Maximum Subcooling (°F)	15	15	15	15
Minimum Superheat at Compressor (°F)	6	6	6	6
Maximum Superheat at Compressor (°F)	12	12	12	12
Maximum Oil Temperature (Max) (°F)	160	200	160	200
Maximum Saturation Discharge Temperature (°F)	120	145	114	145

Note:

1. The minimum/maximum flow rates are based on approximate temperature differential of 5°F to 20°F through the evaporator and 5°F to 30°F through the condenser. Flow rates vary based on application verify with selection software.

Compressor Information

Model UCW/H uses scroll compressors which are highly efficient and extremely reliable. The information contained in this manual will be useful for their care.

Compressor Rotation

All scroll-type machines are unidirectional and will only compress in one direction. Operating in the reverse rotation can be destructive and will be indicated by a loud operating noise together with a lack of compression.

Compressor Anti-Short Cycle Timer

Built into the logic of the CoolLogic Control System is an anti-short cycle timer which will prevent the compressors from restarting immediately following a compressor shutdown. Minimum on 75 seconds and minimum off 200 seconds.

Compressor Lubrication

The compressor operates on a sealed system and oil can only be lost if a leak occurs. There are few cases when oil will need to be added to a machine in normal operation.

Oil Type

The oil in scroll compressors will be either Polyolester type oil (POE) or polyvinyl-ether type oil (PVE). Both refrigerant oils require special handling and should be protected from contamination. They are extremely hygroscopic and will absorb moisture rapidly from the air. It is strongly recommended to store and dispense both oils from sealed metal cans. **Note: Refer to compressor name plate for proper oil type. Different oils cannot be mixed.**

Oil Levels

The oil level in the compressor should be checked with the compressor running. The compressor oil level may vary during operation and particularly on the startup. The normal operating compressor oil level should be between $\frac{1}{3}$ and $\frac{1}{2}$ of the sight glass. During operation, a certain amount of oil is carried out into the refrigerant system. The system has been designed to bring the oil back to the compressor. If the level in the sight glass falls, it may be due to the operating conditions and enough time should be given to allow the oil to return before more oil is added. This could take up to six hours of operation. The compressor should not be allowed to operate with less than $\frac{1}{8}$ of the sight glass for longer than four to six hours.

Adding Oil

The compressor must never be ran in a vacuum. A suitable hydraulic pump should be used to add oil and reserved for this process. **It is imperative that oil type be verified prior to adding to a compressor.** Oil should only be added to a

compressor while it is operating to observe valid oil sight glass levels. Oil is pressure-injected either into a gauge connection on the suction line or injected into the oil process port at the bottom of the compressor housing. Only enough oil should be added to raise the level above the $\frac{1}{3}$ sight glass point.

ATTENTION


To avoid the release of refrigerant into the atmosphere, the refrigerant circuit of this unit must be serviced only by technicians who meet local, state and federal proficiency requirements.

All refrigerant discharged from this unit must be recovered **WITHOUT EXCEPTION**. Technicians must follow industry accepted guidelines and all local, state and federal statues for the recovery and disposal of refrigerants.

If a compressor is removed from the unit, system refrigerant circuit oil will remain in the compressor. To avoid leakage of compressor oil, the refrigerant lines of the compressor must be sealed after it is removed.


CAUTION/ATTENTION	
3 PHASE SCROLL COMPRESSOR UNITS	UNITÉ DE COMPRESSEUR SCROLL 3-PHASE
<p>If this unit uses a 3 Phase Scroll Compressor, the following instructions MUST BE followed:</p> <ul style="list-style-type: none"> • Unit power supply MUST BE wired in the proper sequence to avoid damage to the 3 Phase Scroll Compressor; • Scroll Compressors with INCORRECT rotation show the following characteristics: <ul style="list-style-type: none"> - High sound level; - High suction pressure and low discharge pressure; - Low current draw. • If any of the three above characteristics exist, swap two of the three supply wires at the disconnect and recheck compressor for incorrect rotation. 	<p>Si cet appareil utilise compresseur scroll 3-Phase, les instructions suivantes doivent être suivies:</p> <ul style="list-style-type: none"> • L'alimentation de l'appareil doit être monté dans l'ordre correct pour éviter endommager le compresseur scroll 3-Phase • Compresseurs scroll avec rotation incorrecte montrent les caractéristiques suivantes: <ul style="list-style-type: none"> - Haut niveau de son; - Pression d'aspiration élevée et une faible pression de décharge; - Faible ampérage • Si l'un des trois éléments mentionnés ci-dessus sont remplis, échanger deux des trois lignes électriques alimentant l'interrupteur de sécurité et vérifier la rotation du compresseur.

Refrigeration Circuit Diagram - Cooling Only, Heat Recovery



		TITLE REFRIGERATION CIRCUIT DIAGRAM			
		DESCRIPTION UCW/H WATER COOLED SCROLL CHILLER (REFRIGERANT CIRCUIT #1 OF 2 SHOWN)			
APPROVED	DATE	FILENAME CCE-08001-2.vsd	SIZE A	ClimaCool Corp. CCE-08001-2.VSD	DWG NO CCE-08001-2.VSD
REVISED	SCALE NONE	FILENAME CCE-08001-2.vsd	DRAWN BY Gus Olivera	DATE 04/2012	REV C
			SCALE NONE	DATE 04/2012	SHEET 1 OF 1

Refrigeration Circuit Diagram - Heat Pump



TITLE REFRIGERATION CIRCUIT DIAGRAM		DESCRIPTION UCH WATER COOLED SCROLL HEAT PUMP CHILLER (REFRIGERANT CIRCUIT #1 OF 2 SHOWN)					
		SIZE	A	DWG NO	REV		
APPROVED	DATE	FILENAME	SCALE	DRAWN BY	DATE	SHEET	1 OF 1
		CCE-09001-2.vsd	NONE	Gus Olivera	04/2012	CCE-09001-2.VSD	C

Refrigeration System Re-Processing and Charging

Conforming to local and national codes is the responsibility of the service technician or installing contractor. The service technician should be familiar with the following codes:

- ASHRAE Standard Safety Code for Mechanical Refrigeration, ANSI/ASHRAE 15-1978
- American National Standard Code for Pressure Piping, ANSI B31.5-1974

Factory Tested

ClimaCool modular chillers have been pressure-tested, evacuated, fully charged and run tested at design water flow rates prior to shipment. In the unlikely event that a refrigerant leak is detected at startup, the following guidelines should be consulted before reprocessing the refrigeration systems.

Refrigerant System Reprocessing

Debris and moisture can enter copper tubing in a matter of minutes. All tubing, coil connections or any refrigerant containing portions should be temporarily capped or sealed to keep contaminants to a minimum. Filter driers should be opened just prior to brazing into the system to prevent moisture infiltration whenever possible, and flood the system with low pressure dry nitrogen while brazing to prevent oxidation inside the copper piping.

After all of the repairs have been made to the refrigeration system, a pressure test using refrigerant and nitrogen should be performed. Pressurize the system with dry nitrogen to 20 psi and check for any obvious leaks. If no leaks are present, introduce a “trace” amount of refrigerant to the system (raise system pressure to 30-40 psi). With a dry nitrogen tank equipped with a regulator set to 150 psi, continue to pressurize the system to 150 psi. Using a leak detector, carefully check the system for any remaining leaks. If the system is free of leaks you may release the pressure.

Evacuating the System

The compressors should never run while the system is in a vacuum. This could cause immediate failure to the compressors. After the system has been leak tested and sealed, any moisture that entered the system should be dehydrated and removed. While the pressure is reduced under a vacuum, the boiling point of moisture trapped inside the lines is also reduced. A pressure of .0095 psia, or 500 microns absolute pressure or better must be reached and sustained for several hours in order for the system to be considered free from moisture. It is necessary to use a micron meter equipped with an absolute pressure gauge (or transducer) to take this reading. ClimaCool recommends the triple evacuation process to ensure the proper removal of moisture and contaminants from the refrigeration system. After the initial vacuum is reached and held on the system, allow dry nitrogen back into the system until the pressure reaches zero psig or slightly higher. Then, repeat the entire evacuation process described above. The evacuation process is considered complete **ONLY** after a successful “blank-off” test is performed.

A “blank-off” test is defined as:

- Pulling a vacuum level less than 500 microns on the system and holding it for several hours.
- Record the vacuum level in the system in microns, then close off the vacuum pump from the system for 15 minutes, and continue to monitor the micron level inside the refrigeration system.
- If the vacuum level inside the system does NOT rise more than 400 microns above the recorded vacuum level at the start of the 15 minute period, then the evacuation process is complete.

If the vacuum level rises more than 400 microns in 15 minutes, then continue to evacuate the system for 1-2 hours, and repeat a “blank-off” test.

Recharging the System

After all repairs have been completed, the system has been leak tested and proper vacuum pressures have been reached and maintained, refrigerant may be recharged into the system. With a known weight of refrigerant in the cylinder, use the gauge manifold set to connect the cylinder’s liquid charging port to the charging access port near the refrigerant liquid line valve. Open the compressor suction and discharge line valves, if available. Gradually meter the appropriate weight of liquid refrigerant into the condenser side of the system first, until no additional refrigerant can be dispensed. Accurate refrigerant charge per circuit may be found in the Physical Data information on page 3. Then continue the charging process by filling the evaporator side of the system with refrigerant. Close the refrigerant cylinder charging port, close all gauge manifold ports and start the compressor. Be careful when continuing to charge the balance of the refrigerant, constantly maintaining a positive compressor suction pressure (>25 psig) at all times.

ATTENTION

To avoid the release of refrigerant into the atmosphere, the refrigerant circuit of this unit must be serviced only by technicians who meet local, state and federal proficiency requirements.

All refrigerant discharged from this unit must be recovered **WITHOUT EXCEPTION**. Technicians must follow industry accepted guidelines and all local, state and federal statutes for the recovery and disposal of refrigerants.

If a compressor is removed from the unit, system refrigerant circuit oil will remain in the compressor. To avoid leakage of compressor oil, the refrigerant lines of the compressor must be sealed after it is removed.

⚠ WARNING / AVERTISSEMENT



WATER AND REFRIGERANT SYSTEMS UNDER PRESSURE	EAU ET FRIGORIGÈNE EQUIPEMENTS SOUS PRESSION
<ul style="list-style-type: none">• Isolate/Lockout source and relieve pressure BEFORE servicing equipment.• Failure to relieve pressure may result in property damage, serious bodily injury or death!	<ul style="list-style-type: none">• Isoler la source / de verrouillage et de soulager la pression avant entretien de l'équipement.• Le défaut de soulager la pression peut entraîner des dommages matériels, des blessures corporelles graves ou la mort!

Engineering Guide Specifications

General

Factory-assembled and wired water cooled, water chiller. Chiller consists of two compressors, one evaporator and condenser, safety and operational controls. The modular water cooled package chiller shall incorporate one or more modules with two independent refrigerant circuits. Modules shall be capable of independent operation powered by a field installed fused disconnect switch (or equivalent circuit breaker) supplied by others, so that any one module can be shut down for repair without interrupting the remaining chiller modules in operation.

Basic Construction

The frame design shall consist of heavy gauge galvanized steel with 3 mil powder coat paint finish baked at 350° for resilience in transport and installation. The module must have a low center of gravity, detachable schedule 40 carbon steel pipe water headers, designed to connect to adjacent modules through the use of 300 psi rated grooved couplings, base with cutouts for forklift or pallet jack and the frame must be designed to fit through a standard 36" doorway. Each module has sound attenuation panels to ensure quiet operation.

Refrigeration Circuit

All refrigeration circuits shall contain R-410A non-ozone depleting HFC. Each independent circuit shall consist of a scroll compressor, thermostatic expansion valve for refrigerant metering, sight glass, filter drier and high and low pressure safety controls. The modular chiller bank must be able to produce chilled water even in the event of a failure of one or more refrigerant circuits.

Evaporator

Each evaporator shall be highly efficient, refrigerant-to-water, dual circuited, brazed plate heat exchangers constructed of 300 stainless steel; designed, tested, and UL stamped in accordance with ASME Section VIII pressure vessel code for 650 psig working refrigerant pressure. The evaporator heat exchanger shall be mounted to eliminate the effect of migration of refrigerant to the cold evaporation with consequent liquid slugging on startup. The evaporator shall be mounted on two layers of noise attenuating rubber isolation pads which also act as a thermal barrier. The evaporator shall be wrapped with ¾" closed cell insulated blanket. The closed cell insulation shall be provided on suction side refrigerant tubing including refrigerant-to-chiller heat exchanger to prevent condensation

Condenser

Each condenser shall be highly efficient, refrigerant-to-water, dual circuited, brazed plate heat exchangers

constructed of 300 stainless steel; designed, tested, and UL stamped in accordance with ASME Section VIII pressure vessel code for 650 psig working refrigerant pressure on the condenser. The condenser heat exchanger shall be mounted to eliminate the effect refrigerant migration to the cold evaporation with consequent liquid slugging on startup. The condenser shall be mounted on two layers of noise attenuating rubber isolation pads which also acts as a thermal barrier.

Compressors

Each module shall contain two scroll compressors independently circuited for redundancy. Each compressor shall be mounted with rubber isolated compressor mounts to the module base and each shall include compressor overload protection, high discharge pressure and low suction pressure cutouts.

Control Panel

Master Controllers shall be provided for individual control as well as system integration. The control shall consist of a simple two-conductor shielded daisy chain connection to allow communication between modules with minimal field wiring. The remote air cooled chiller control panel shall be a NEMA Type 1 enclosure including: power distribution block, compressor fusing, contactors, finger safe control fusing, transformer, isolation relays, status and alarm relay, 16-bit microprocessor master controller with built in native Building Automation System (BAS) communication protocols, (BACnet, LonWorks, Modbus and N2), status indicating lights showing: 1) compressor operation (on/off), 2) unit alarm status, 3) power on, two toggle switches to disable each individual compressor during start-up or troubleshooting.

CoolLogic Control System

Remote Master Control system shall be fully compatible with the Building Automation System via native BACnet and LonWorks, Modbus and N2 communication. Scheduling of the various compressors shall be performed by the master microprocessor based controller. A compressor run time equalization sequence is provided to ensure even distribution of compressor run time. A load limit control shall be available to limit the number of compressors that can be energized at one time.

The CoolLogic Control System shall monitor and report the following for each refrigeration circuit in each module:

- Discharge pressure and temperature faults
- Suction pressure and temperature faults
- Compressor winding high temperature fault
- Low evaporator leaving chilled water temperature fault

Engineering Guide Specifications

The Master Controller shall monitor and report the following system parameters for the chiller system:

- Chilled water entering and leaving temperature
- Condenser water entering and leaving temperature
- Evaporator and condenser water flow availability

Any module failure condition shall cause a “fault” indication at the Master Control Panel and shutdown of that compressor circuit with the transfer of the load requirements to the next available compressor circuit. In the case of a system “fault” the entire chiller will be shut down. When any fault occurs, the *CoolLogic* Control System shall record conditions at the time of the fault, and store the data for recall. This information shall be capable of recall through the keypad of the Master Control Panel and displayed on the 4 line by 40 character, back-lit LCD. A history of faults shall be maintained including date and time for each fault (up to the last 100 occurrences). Internal leaving chilled water reset control will insure that the parallel evaporators are operated above the freeze point for part load operation.

Factory Testing

Each remote air cooled chiller module shall be pressure-tested, evacuated and charged with nitrogen.

Options and Accessories

Automatic CS Series Strainer Package

Field installed, high quality, low maintenance stainless steel filtration systems with 60 or 80 mesh stainless steel screens will reduce operating costs and prevent nuisance condenser issues. Strainer package can be equipped with optional pressure differential alarm and automatic time flush.

Heat Pump

Factory installed reverse cycle heating and cooling operation compatible with boiler/tower or geothermal systems.

Heat Recovery

Factory installed option providing hot water, as high as 140°F, while simultaneously producing chilled water for the chiller system.

Hot Gas Bypass

Factory installed on both circuits allowing unit operation below the minimum step of unloading.

Manual Strainers

Field installed strainers utilize Y-style and Basket strainers of cast iron 200 psi or carbon 275 psi with 60 mesh stainless steel screens to increase efficiency and ensure long equipment life. All strainers are field installed external to the chiller bank for ease of service.

Motorized or Manual Water Isolation Valves and Flush Ports

Factory installed water isolation valves and flush ports shall provide isolation to the module for maintenance and cleaning of evaporator and condenser heat exchangers while adjacent modules continue normal operation. Both motorized and manual valves include standard ¾" fill and flush valves. **Note: All Heat Pump configurations require motorized valves.**

Motorized condenser water valves provide head pressure regulation for low entering condenser water temperature applications (less than 60°F).

Available choices include:

- One each motorized valve for evaporator and condenser with one each manual valves for the evaporator and condenser.
- One each motorized valve for the evaporator and one each manual valve for the evaporator and two each manual valves for the condenser.
- Two each manual valves for the evaporator and the condenser.

Pressure Differential Flow Sensor

Field installed to prevent operation of chiller without sufficient water flow to the evaporator and/or condenser.

Seismic Certification

Factory installed seismic tested in accordance with OSHPD standards for cooling only chillers.

Water Header Bypass

Field installed water header bypass may be utilized to prevent deadheading the pump. A bypass is mandatory with all motorized valve applications.

Options available for following:

Direct Return:


- Motorized evaporator/condenser water isolation valves
- Motorized evaporator/manual condenser water isolation valves

Reverse Return:

- Motorized evaporator/condenser water isolation valves
- Motorized evaporator/manual condenser water isolation valves

Stainless Steel Strainer Option

Figure 27 - Stainless Steel Strainer



Safety Considerations

Prior to installation, this manual must be read carefully and all instruction understood. Personal injury or product damage can occur if the following safety precautions are overlooked or ignored. We strongly recommend that you follow these safety precautions and avoid the potential hazards listed below when operating and maintaining the strainer:

1. After unpacking your strainer, carefully inspect your strainer housing, lid assembly and screen for damaged or missing parts. Contact ClimaCool's customer service department for any replacement parts.
2. The strainer should not be modified or used in a manner not consistent with the manufacture's recommendations. If there are any questions regarding its application or installations, contact ClimaCool's customer service department.
3. Absolutely under no conditions should the strainer lid or pressure gauges be removed while the strainer is pressurized.
4. Standard bolted lid models should never exceed 150 psi; V-Band clamp models should never exceed 125 psi.
5. Install back-flow prevention devices (or check valves) both upstream and downstream of the strainer to prevent back flow or vacuum effects which can cause damage to the strainer housing or screen.
6. Install properly sized pressure relief valves both upstream and downstream of the strainer. This will help prevent damage to the strainer and screen in the event that water flow is stopped abruptly, or if water hammering occurs. The pressure relief valves should be set to relieve pressure at 1.2 times the strainer's maximum operating pressure (not to exceed the maximum rated pressure). Consult your local dealer or pressure relief valve manufacturer to obtain properly sized valves for your application.

Note: Minimum 60 mesh screen is required. At no time should the internal pressure exceed the maximum rated pressure of the strainer.

Strainer Installation Recommendations

Follow the recommended guidelines below for strainer installation:

1. The Carbon Steel (CS) strainer should be placed on a firm, supporting surface. Failure to do so can cause stress on the weld joints. It is recommended a concrete pad be poured under the base of the strainer. The weight of the CS strainer should not be supported by the main water lines connecting it.
2. The inlet and outlet connections should be securely fastened. The arrows depict flow direction (see Figure 27).
3. The back-mount pressure gauges should be installed in the gauge ports located on the front of the strainer body. These gauges will allow you to monitor the pressure differential across the strainer screen providing an indication when the strainer element is clogged and requires cleaning.
4. The CS strainer lid must be securely fastened according to the following torque specifications to ensure product safety and an adequate seal.

Torque Specifications

Clamped Lid Models: CS strainer models 3CS and 4CS have "over-center latch clamp" lid designs. The over-center clamp does not require adjustment when installing or removing the lid. The lock washer is set at the factory for proper clamp compression and normally requires no field adjustment. Minor tightening may be necessary over time. The lids are installed as follows:

1. Place the clamp around the strainer lid.
2. Latch the T-bolt with the receiver and push the latch handle towards the strainer body until the safety catch engages.

Bolted Lid Models: CS strainer models 6CS, 8CS and 10CS have "bolted" lid designs. Grade 5 zinc-plated bolts, nuts and washers are used to attach the lids to these strainers. See Table 3 for proper lid bolt size and torque rating for each strainer (See page 43). (Exercise care when tightening the lid bolts so as not to damage the strainer lid or housing).


It is important to follow the torque specifications as over-tightening may result in premature failure of the bolts. It is equally important to follow a star wheel torque pattern when tightening the lid bolts (See Figure 28). The strainer lid may not be seated down completely after the first torque sequence. A second torque sequence should be adequate to seat the lid securely to the body.

Stainless Steel Strainer Option

Table 3

Strainer	Bolt Size (Inches)	Recommended Torque (ft. lbs)
3CS	5/16 - 18	60 - 80
4CS	3/8 - 16	15 - 25
6CS	1/2 - 13	45 - 55
8CS	1/2 - 13	45 - 55
10CS	5/8 - 11	80 - 100

Figure 28 - Recommended Torquing Sequence



Strainer Operation

Periodically, it will be necessary to flush out the debris that is collected and settles to the bottom of the strainer reservoir. CS-3 strainers must have a valve installed on the drainage port. The larger CS strainers (4CS, 6CS, 8CS and 10CS) are equipped with a flush port (or drainage port) extending inside the strainer. When it becomes time to clean the strainer, the flush port valve should be opened while the strainer is in operation (while pressurized and with water flowing). A thorough flushing of the strainer reservoir will depend upon the length of time the flush valve remains opened. This flush time will typically range from 15 to 60 seconds depending on the flow, inlet water pressure and the amount of debris collected by the strainer. As a general rule, the larger strainers will require higher inlet water pressures in order to achieve a complete flushing. For example, the 4CS model can be flushed with inlet water pressures as low as 15-20 psi, while the 6CS can be flushed with 30-35 psi. The 8CS and 10CS models should be flushed with inlet water pressures greater than 40 psi.

Note: When shutting down the chiller for extended periods of time, the strainer should be isolated and completely drained.

Strainer Element Cleaning

If your strainer assembly is equipped with optional pressure gauges, you will be able to monitor the pressure differential between the inlet and outlet sides of the strainer. When this pressure differential reaches 5-10 psi the strainer element may require cleaning.

Caution: Prior to dismantling the strainer for cleaning, it is imperative that the strainer assembly is isolated and completely de-pressurized.

Follow the steps below when cleaning the CS strainer element:

- Step 1.** (Bolted Lid Models): Remove the top of the strainer by removing the Grade 5 Zinc plated bolts from the lid.
- Step 1.** (Clamped Lid Models): Remove the top of the strainer by taking off the band-clamp assembly.*
- Step 2.** Lift the strainer element (conical screen) out of the strainer body.
- Step 3.** Carefully scrub down the strainer element with a rigid nylon brush until all matter is loosened.
Do not use a steel brush.
- Step 4.** Wash the strainer element off with clean water. It is preferable to use a hose with a significant amount of water pressure.
Do not use a pressure washer.
- Step 5.** Wash all matter from the strainer gaskets and clean the inner-ring where the bottom of the strainer element rests.
- Step 6.** Make sure the U-shaped gasket is fitted securely to the bottom of the strainer element.
Reposition the strainer element into the body of the strainer.
- Step 7.** Make sure the strainer head gasket is secure on top of the strainer body. On V-band models, O-rings should be seated completely in the body flange. Reposition the strainer lid back on the strainer body. **Tighten the lid securely either with the bolts or with the band-clamp.**

* For clamped models, opening and closing is achieved without adjusting the lock nut. It is tightened at the factory to the correct compression. (Minor tightening may be necessary if the gasket loses memory over time.) To open the clamp, depress the safety latch and pull the over-center lever outward. To close the clamp, make sure the T-bolt is seated in its receiver and push the over-center lever back toward the strainer housing. **Be sure that the safety latch is engaged before putting the unit to use.**

Stainless Steel Strainer Option

What is Water Hammer?

Water hammer is a phenomenon that can occur in fluid systems with long pipes. Water hammer is a rapid change of pressure caused by a rapid change in velocity. If the flow has been abruptly shut off downstream, the pressure in the entire system is raised very quickly.

What Causes Water Hammer?

Any action that can cause a rapid change in the velocity of the flow can set off a water hammer, such as closing a downstream valve, pump stoppage, etc. Typically, for short lengths of pipe (below 500 feet) downstream valves that are closed within 1/10 of a second can generate water hammer.

What Can Water Hammer Do?

Pressure spikes from water hammer can raise fluid pressures to dangerously high values. These pressure spikes can cause serious damage to valves, pipes, strainers, joints, etc. The CS strainer is rated to an absolute maximum pressure of 150 psi for bolted lid models, and 125 psi for clamped lid models. A water hammer pressure spike that raises the pressure higher than the maximum rated pressure may result in strainer damage, voiding the manufacturer's warranty.

What Can I Do to Prevent Water Hammer?

There are certain precautions that can be taken to prevent or decrease the effect of water hammer. The addition of a surge tank or accumulator fitted with a suitable pressure relief valve strategically located within the water system may provide adequate protection against the effects from water hammer. Careful attention should be given to the design and control strategy for valves and pumps so their actions do not invite a water hammer.

Stainless Steel Strainer Options

Automatic Timer Flush (ATF) Package Option

The ATF-EA-1.5 flush valve package provides an automatic method for flushing away the debris collected in the strainer's reservoir. The power supply and timer controls for the valve package are housed inside the ATF control box. The ATF controls can be pre-programmed to set the flushing duration and the time interval between flushes.

System Components

1. Timer based valve controller: (see Figure 29) sets the flush duration (length of the flush) and the flush interval (time between flushes).
2. Electric Ball Valve: designed for dirty water use (see Figures 29 and 30).

Figure 29




Figure 30





Figure 31



Valve Specifications (See Figure 31)

- A. Water-resistant polypropylene motor case
- B. High torque motors with perma-lube gears
- C. Open and close indicator
- D. Stainless steel ball valve and hardware
- E. Auto reset circuit breaker
- F. 90° bi-directional rotation
- G. Controller case

Stainless Steel Strainer Option

Operation Instructions

Flush valve line must be piped to atmospheric pressure such as an open floor drain. The flush line should not undergo any changes in elevation and should be sloped downward in the direction of drainage. **Do not pipe the flush or drain line into a pressurized line.**

Note: The Automatic Timer Flush Package needs to be programmed when it is received by the end-user. The programming is simple and takes only a few moments. However, because every application has different parameters that affect the required frequency between flushes and the duration of the flush, the end-user must choose the controller's settings (refer to your specific strainer manual).

To Program the ATF Controller

1. Plug the transformer into a 120-VAC outlet.
2. Insert the 12-VDC plug coming from the transformer into the jack on the underside of the ATF box.
3. Test for power by pressing the manual flush side of the control switch (lower switch light should come on then the valve will start to open).
4. Adjust the "ON TIME" (Valve Open) by turning the inner timer ring with the GREEN POINTER clockwise to increase duration. The ON TIME RANGE is factory set at eight seconds. (See Figure 29).
5. Adjust the "OFF TIME" (Valve Close) by turning the outer ring with the RED POINTER clockwise to increase duration. The OFF TIME RANGE is factory set at twenty-four (24) hours. (See Figure 29).
6. Set the control switch to auto flush. The red off light on the timer will come on and the upper light on the switch will come on and stay on. During the flush cycle the on light on the timer and the lower switch light will come on.

Control Switch

Control switch flushing is initiated by pressing and holding down the manual control switch located on the front of the controller (See Figure 30). The manual flush control switch can also be used to conveniently drain the water out of the strainer before removing the conical screen element from the strainer housing. A yellow indicator arrow on top of the ATF valve will rotate in sync with the ball valve to show the valve position (open or closed). When the manual flush control switch is released, the valve will automatically close.

SAFETY FIRST! - Keep fingers away from valve opening to avoid getting caught in the moving parts. The electric motor supplied a sufficient amount of power to cause personal injury. Take precaution when handling.


Water Resistance

The valve and controller are water-resistant, but not water-proof. Do not install below ground level where the component can be submerged in water. Only remove the cover plate from the valve controller when setting or changing the flush settings. Keep the cover tightly sealed on the unit during normal operation.

Pressure Differential Alarm Package Option

The pressure differential alarm (PDA) option continually monitors and displays the strainer's inlet and outlet differential pressure. When the strainer element (conical strainer basket) becomes significantly clogged, the pressure differential switch-gauge will trigger an audible siren and a visual flashing alarm light. These alarms are intended to alert maintenance personnel that the strainer element must be removed and cleaned (See Strainer Element Cleaning on page 43).

Figure 32



Operation Instructions

Remove the power supply and insert the connector end into the socket on the bottom of the PDA housing (See Figure 32 above) and plug the transformer into the power source. Standard systems are supplied with a 120V power supply to the primary of the transformer, with an output secondary of 12 VDC. The pressure differential switch-gauge is factory set to 7-8 psi. The CS strainer operates at a pressure differential slightly less than 1 psi during maximum flow when the strainer screen is clean. By the time the differential pressure reaches 7-8 psi, the strainer element will be significantly clogged and require immediate removal and cleaning. To adjust the pressure differential switch-gauge setting, insert a 1/16" allen wrench and rotate the differential set point contact to the desired location (See Figure 32). **Note: It is not recommended to set the differential switch-gauge higher than 10 psi. Disabling the alarm or increasing the alarm set point could result in damage to the strainer element and allow debris to pass into the system.**

Stainless Steel Strainer Option

When the differential set point is reached both the audible and visual alarms will be triggered and will remain engaged until both the alarm condition is corrected and the alarm-reset button is pressed (if the alarm-reset button is pressed but the differential pressure is beyond the set point, the alarms will re-engage immediately). After the strainer is cleaned and put back in service, the differential pressure should return to 1 psi.

Auxiliary Contacts

The PDA option is equipped with a remote alarm feature. The remote alarm contacts are located at the two black and red banana clip posts (See Figure 32). The alarm can be set up in one of two ways:

1. A remote alarm signal of 12 VDC can be sent to a central monitoring station or
2. A set of auxiliary contacts will indicate a “closed” condition when the alarm activates. (Locate the Auxiliary Contact Schematic inside the PDA box by removing the four screws on the cover plate).

Water Resistance

The Pressure Differential Alarm Controller is water-resistant, but not water proof. Do not install below ground level where the box can be submerged in water. **Do not remove** the cover plate from the PDA controller. Keep the cover tightly sealed on the module during normal operation.

Table 4

Troubleshooting for ATF Package		
Problem		Solution
Valve is leaking past ball	• Seals damaged or worn out	• Install repair kit
	• Valve is not stopping at proper closed position	• Adjust limit switches
Valve stem leaks	• Worn stem seals	On metal valves: tighten stem packing nut 1/2 turn. • CAUTION! Over tightening stem nut could cause drag on motor and trip internal circuit breaker. May require repair kit or new valve.
Valve body leaks	• Loose body bolts or excessive operation pressure	• Check bolts and observe recommended pressure ratings
	• Defective seals	• Install repair kits or new valve
Valve hard to turn	• Swollen seals or product buildup in valve chamber	• Check valve for compatibility with product, may require valve cleaning or new valve
	• Valve bolts too tight	• Loosen bolts slightly
	• Stem nut too tight	• Loosen stem nut slightly

WYE Strainers

Pre Installation Checklist:

1. Ensure working conditions (pressure/temperature) are within the specified capacity of the product being installed. Please refer to the certified drawings to assist in determining these values.
2. Inspect all sealing surfaces to ensure gasket surfaces are free of defects (no nicks or cuts). The pipeline should also be checked for proper alignment. WYE strainers should never be utilized to realign an existing piping system.
3. Ensure that the pipeline's mating flanges are the same type as the WYE strainer being installed. Raised face flange ends cannot be mated to flat face flange ends.
4. Ensure strainer end-to-end length and installation gap are within $\frac{1}{4}$ in gap for gasket, and have sufficient clearance for easy opening of cover and screen removal.
5. If the WYE strainer is to be located on the discharge side of a pump, then a safety release valve must be installed between the WYE strainer and the pump.

Figure 33: WYE Strainer Straining Illustration





Figure 34: WYE Strainer - Flanged Ends



Installation Procedure:

1. Also, for maximum efficiency, install a differential pressure gauge at inlet and outlet connections or at the strainer gauge tap (if provided).
2. WYE strainers must be positioned in the pipeline ahead of the equipment requiring protection.
3. To provide for easier maintenance, the WYE strainer should be located where the drain plug can be removed. Additionally, ensure the drain or blow-off is located at the lowest position when installed. If installed in the vertical position, the WYE side of the strainer must be pointing downward.
4. Ensure there is ample space at the WYE side of the strainer for screen removal.
5. Before placing the WYE strainer into place, support the existing pipeline with pipe supports near the inlet and outlet connections.
6. Place the WYE strainer into the pipeline ensuring that the flow arrow on the body of the WYE strainer is pointing in the direction of the pipeline flow. For large or heavy strainers, appropriate material handling equipment must be used.
7. Install a standard ANSI ($\frac{1}{8}$ " thick) flange gasket between the WYE strainer and pipeline flanges, on both sides. Install lubricated flange bolts and hand tighten. Flange bolts should then be tightened, using a star or crisscross pattern to evenly load the bolts, in accordance with established piping standards. This is illustrated in Figure 35.

Figure 35: Bolting Sequence Pattern



Note: Excessive bolt torque may damage flanges. Please refer to established flange bolt torques for guidelines.

Operation

Once proper installation has been successfully completed, start the system gradually, at start up as well as after shut down. This eliminates sudden shock to the strainer and other equipment in the line. This is extremely important for steam service.

WYE Strainers

Start-Up Procedure

1. To remove all fluid from the strainer belly, a drip-leg can be installed or the piping can be placed at a ¼" slope.
Note: With piping systems that contain fluids other than water or when the working temperature is above 120°F, fluid must be drained to safe area, away from the operator. Operators should always be fitted with appropriate equipment (goggles, gloves, vests etc.) when venting or servicing is performed.
2. Start the piping system by opening the outlet valve nearest the WYE strainer's outlet first. Then gradually open the inlet valve nearest the WYE strainers' inlet, approximately 25% of normal operational flow. It is important to start the system gradually to avoid displacing or damaging the WYE strainer.
3. Continue to open the inlet valve until the desired service flow has been reached.

Maintenance

WYE strainers require little monitoring once they are properly installed. The pressure differential across the strainer should be checked periodically to determine if the screen needs to be cleaned or replaced. If the pressure differential goes unchecked and the screen becomes completely clogged, the screen will break and require replacing. **Note:** Strainer screens are not designed to withstand the same pressure ratings as the housings. If the screen becomes completely clogged, it will be exposed to the same pressure as the housing. In most cases, this will cause the screen to fail and potentially damage downstream equipment.

Regular maintenance involves:

- Timely cleaning or replacement of screen
- Periodically checking for leaks

During normal use, the screen will become clogged with foreign matter, causing the differential pressure to increase. Once the differential pressure has increased to an unacceptable value, typically by 5 psi to 10 psi, it is time to clean or replace the screen. It is not advisable to let the differential pressure increase by 20 psi. This may cause the screen to fail and possibly damage downstream equipment.

A convenient and safe way to determine when the screen needs to be replaced is to install pressure gauges on the inlet and outlet sides of the strainer. The maximum acceptable pressure drop across the strainer will indicate when the screen needs to be replaced. Screen size and construction determine the maximum pressure drop that a strainer screen can withstand.

Screen Removal/Cleaning/Replacement

1. Isolate the strainer by closing the inlet and outlet valve connections on either side of the WYE strainer. Make sure valves are bubble tight.
2. Open vent to relieve pressure inside and drain fluid from the strainer.
3. Once pressure is relieved, remove the WYE side cap or cover.
4. Remove screen and clean. Do not permit screen to dry as it will be difficult to remove debris after it has hardened. Avoid banging or hitting the screen to remove stubborn debris.
5. Inspect screen and cover gasket for damage. If either is damaged, replace. Always ensure there is a spare gasket and screen on hand prior to maintenance.
6. Remove any debris or sludge from within the strainer.
7. Replace cleaned or new screen into its original position, ensuring it is squarely positioned on the screen.
8. Replace cover gasket and cap or cover. Tighten cap or cover to specified torque rating.

Follow the Start-up procedure outlined within the Operation Instructions.


Basket Strainers

The correct size of Basket Strainer is determined by its job function, not by the size of the pipeline.

Pre Installation Checklist:

1. Inspect the basket strainer's flange ends and the pipeline's mating flanges to ensure gasket surfaces are free of defects. The pipeline should also be checked for proper alignment. Strainers should never be utilized to realign an existing piping system.
2. Ensure that the pipeline's mating flanges are the same type as the basket strainer being installed. Raised face flange ends cannot be mated to flat face flange ends.
3. Ensure that the pipeline setup allows a horizontal installation of the basket strainer.
4. If pipeline strain is a concern when installing larger basket strainers (6" and above), a concrete or steel pad should be used to provide additional support. Larger basket strainers can also be fitted with legs to assist in reducing strain on the pipeline.
5. If the basket strainer is to be located on the discharge side of a pump, then a safety release valve must be installed between the basket strainer and the pump.

Figure 36 - Installed Basket Strainer with Bolted Cover




Installation Procedure:

1. To provide for easier maintenance, the basket strainer should be located where the drain plug can be removed and where there is ample space above the basket strainer for screen removal.
2. Before placing the basket strainer into place, support the existing pipeline with pipe supports near the inlet and outlet connections of the basket strainer.
3. Place the basket strainer into the pipeline ensuring that the flow arrow on the body of the basket strainer is pointing in the direction of the pipeline flow. For large or heavy strainers, lift the basket strainer into place using slings positioned underneath the inlet and outlet connections.

4. Install a standard ANSI ($\frac{1}{8}$ " thick) flange gasket between the basket strainer and pipeline flanges, on both sides. Install lubricated flange bolts and hand tighten. Flange bolts should then be tightened, using a star or crisscross pattern to evenly load the bolts, in accordance with established piping standards. This is illustrated in Figure 37.

Figure 37: Bolting Sequence Pattern



Note: Excessive bolt torque may damage flanges. Please refer to established flange bolt torques for guidelines.

Operation

Once proper installation has been successfully completed, start the system gradually, at start up as well as after shut down. This eliminates sudden shock to the strainer and other equipment in the line. This is extremely important for steam service.

Start-Up Procedure

1. Remove air from the pipeline by opening the vent near the basket strainer. **Note:** With piping systems that contain fluids other than water or when the working temperature is above 120°F, fluid must be drained to safe area, away from the operator. Operators should always be fitted with appropriate equipment (goggles, gloves, vests etc.) when venting or servicing is performed.
2. Start the piping system by opening the outlet valve nearest the basket strainer's outlet first. Then gradually open the inlet valve nearest the basket strainer's inlet, approximately 25% of normal operational flow. It is important to start the system gradually to avoid displacing or damaging the basket strainer.
3. Continue to open the inlet valve until the desired service flow has been reached.

Start the piping system by opening the outlet valve nearest the basket strainer's outlet first. Then gradually open the inlet valve nearest the basket strainer's inlet, approximately 25% of normal operational flow. It is important to start the system gradually to avoid displacing or damaging the basket strainer. Continue to open the inlet valve until the desired service flow has been reached.

Basket Strainers

Maintenance

Basket strainers require little monitoring once they are properly installed. The pressure differential across the strainer should be checked periodically to determine if the screen needs to be cleaned or replaced. If the pressure differential goes unchecked and the screen becomes completely clogged, the screen will break and require replacing. **Note:** Strainer screens are not designed to withstand the same pressure ratings as the housings. If the basket becomes completely clogged, it will be exposed to the same pressure as the housing. In most cases, this will cause the basket to fail and potentially damage downstream equipment.

Regular maintenance involves:

- Periodically checking for leaks
- Timely cleaning or replacement of screen

During normal use, the basket will become clogged with foreign matter, causing the differential pressure to increase. Once the differential pressure has increased to an unacceptable value, typically by 5 psi to 10 psi, it is time to clean or replace the screen. It is not advisable to let the differential pressure increase by 20 psi. This may cause the screen to fail and possibly damage downstream equipment.

A convenient and safe way to determine when the screen needs to be replaced is to install pressure gauges on the inlet and outlet sides of the strainer. The maximum acceptable pressure drop across the strainer will indicate when the screen needs to be replaced. Screen size and construction determine the maximum pressure drop that a strainer screen can withstand. Please consult factory for exact pressure ratings.

Strainer Element Cleaning

Before removing the cover of the basket strainer, the pressure inside the vessel must be reduced to atmospheric via suction or venting. Failure to do so may result in serious bodily injury.

1. Isolate the basket strainer by closing the inlet and outlet valve connections on either side of the basket strainer.
2. Open vent or drain plug to relieve pressure inside the basket strainer. Drain fluid up to screen seat level.
3. Once pressure is relieved, remove the cover.
4. Remove baskets and clean. Avoid banging or hitting the screen to remove stubborn debris.
5. Inspect basket and cover gasket for damage. If either is damaged, replace. Always ensure there is a spare gasket and basket on hand prior to maintenance.

6. Remove any debris or sludge from within the basket strainer.
7. Replace clean basket into its original position, ensuring it is squarely positioned on the screen seat.
8. Replace cover gasket and replace and tighten cover.

Follow the Start-up procedure outlines within the Operation Instructions.

Electrical Data UCW

Model Type	Model #	Voltage	Power Wiring - per Module				Internal Wiring - per Compressor					
			Rated Load Amps ¹	Min.Cir. Amps (MCA) ²	MaxFuse Size (MOP) ^{3,4}	Rec. Fuse Size ^{4,5}	Discon. Switch Size ⁶	Rated Load Amps ¹	Min.Cir. Amps (MCA) ²	Locked Rotor (LRA) ⁷	MaxBreaker Size (MOP) ³	Rec. Fuse Size ⁵
UCW030	UCW030AHASAXBoS	208-230/3/60	85	96	125	110	150	42.7	53.3	425	90	70
	UCW030AFASAXBoS	460/3/60	39	43	60	50	70	19.3	24.1	187	40	30
	UCW030ANASAXBoS	575/3/60	31	35	50	40	50	15.4	19.3	148	30	25
UCW050	UCW050AHASAXBoS	208-230/3/60	147	166	225	200	225	73.7	92.1	500	150	N/A
	UCW050AFASAXBoS	460/3/60	67	75	100	90	100	33.3	41.7	250	70	60
	UCW050ANASAXBoS	575/3/60	53	60	80	70	80	26.7	33.3	198	50	45
UCW070	UCW070AHASAXBoS	208-230/3/60	190	214	300	250	300	95.1	118.9	600	200	N/A
	UCW070AFASAXBoS	460/3/60	86	97	125	110	150	43.0	53.8	310	90	70
	UCW070ANASAXBoS	575/3/60	69	77	110	90	110	34.4	43.0	255	70	60
UCW085	UCW085AHASAXBoS	208-230/3/60	225	253	350	300	350	112.4	140.5	732	250	N/A
	UCW085AFASAXBoS	460/3/60	102	115	175	150	175	50.8	63.5	368	110	N/A
	UCW085ANASAXBoS	575/3/60	82	92	125	110	125	40.7	50.8	292	90	70

NOTES:

1. RLA - Rated Load Amps are calculated as per UL1995.
2. MCA - Minimum Circuit Ampacity is: 125% of the RLA of the largest compressor motor plus 100% of the RLA of all other concurrent motors and/or electrical loads.
3. MOP - Maximum Overcurrent Protected Device Amp Size is rounded down from: 225% of the RLA of the largest compressor motor plus 100% of the RLA of all other concurrent electrical loads.
4. MOP Device or Recommended Fusing Device for Module Power Wiring supplied by others. These are recommended values for electrical power protection of modules selected.
5. Recommended Dual Element Fuse Sizing: Rounded up from 150% of the RLA of the largest compressor motor plus 100% of the RLA
6. Disconnect Switch for Module Power Wiring supplied by others. These are recommended values for electrical power
7. LRA - Locked Rotor Amps are instantaneous starting amperage per compressor.
8. Module internal wiring is per NEC.
9. Voltage Tolerance Range:

208-230V / 60 Hz:	Min. 187V	Max. 253V
460V / 60 Hz:	Min. 414V	Max. 506V
575V / 60 Hz:	Min. 518V	Max. 632V

Model Type	Model #	Voltage	Power Wiring - per Module						Internal Wiring - per Compressor				
			Rated Load Amps ¹	Min. Cir. Amps (MCA) ²	MaxFuse Size (MOP) ^{3,4}	Rec. Fuse Size ^{4,5}	Discon. Switch Size ⁶	Rated Load Amps ¹	Min. Cir. Amps (MCA) ²	Locked Rotor (LRA) ⁷	MaxBreaker Size (MOP) ³	Rec. Fuse Size ^{4,5}	
UCHo3o	UCHo3oAHASAXBos	208-230/3/60	113	127	175	150	175	56.4	70.5	425	125	N/A	
	UCHo3oAFASAXBos	460/3/60	51	57	80	70	80	25.5	31.9	173	50	40	
	UCHo3oANASAXBos	575/3/60	41	46	60	60	70	20.4	25.5	128	45	35	
UCHo5o	UCHo5oAHASAXBos	208-230/3/60	189	213	300	250	300	94.7	118.4	605	200	N/A	
	UCHo5oAFASAXBos	460/3/60	86	96	125	110	150	42.8	53.5	272	90	70	
	UCHo5oANASAXBos	575/3/60	69	77	110	90	110	34.3	42.8	238	70	60	
UCHo7o	UCHo7oAHASAXBos	208-230/3/60	249	280	400	325	400	124.3	155.4	599	250	N/A	
	UCHo7oAFASAXBos	460/3/60	112	126	175	150	175	56.2	70.3	310	125	N/A	
	UCHo7oANASAXBos	575/3/60	90	101	125	125	150	45.0	56.2	239	100	70	
UCHo85	UCHo85AHASAXBos	208-230/3/60	317	357	500	400	500	158.5	198.1	732	350	N/A	
	UCHo85AFASAXBos	460/3/60	144	162	225	200	225	71.7	89.6	368	150	N/A	
	UCHo85ANASAXBos	575/3/60	115	129	175	150	175	57.3	71.7	292	125	N/A	


NOTES:

1. RLA - Rated Load Amps are calculated as per UL1995.
2. MCA - Minimum Circuit Ampacity is: 125% of the RLA of the largest compressor motor plus 100% of the RLA of all other concurrent motors and/or electrical loads.
3. MOP - Maximum Overcurrent Protected device amp size is rounded down from: 225% of the RLA of the largest compressor motor plus 100% of the RLA of all other concurrent electrical loads.
4. MOP Device or Recommended Fusing Device for Module Power Wiring supplied by others. These are recommended values for electrical power protection of modules selected.
5. Recommended Dual Element Fuse Sizing: Rounded up from 150% of the RLA of the largest compressor motor plus 100% of the RLA of all other concurrent electrical loads.
6. Disconnect Switch for Module Power Wiring supplied by others. These are recommended values for electrical power protection of modules selected.
7. LRA - Locked Rotor Amps are instantaneous starting amperage per compressor.
8. Module internal wiring is per NEC.
9. Voltage Tolerance Range:

208-230V / 60 Hz:	Min. 187V	Max. 253V
460V / 60 Hz:	Min. 414V	Max. 506V
575V / 60 Hz:	Min. 518V	Max. 632V

Power Distribution Drawing

Figure 38



Notes:

1. Breaker panel represents field power supply and is to be installed by others. Not provided as part of the ClimaCool modular chiller system.
2. Breaker panels can be supplied for skid mount pump/tank packages or new construction projects as options. Consult your local ClimaCool Representative.
3. Control wiring by others.
4. Field connections are simplified requiring only a two-conductor shielded cable daisy chain from the master controller to the modules. (See Figure 38).

Specifications for ARC156 Wiring

- Description - Single twisted pair, low capacitance, CL2P, TC foam FEP, plenum rated cable
- Conductor - 18 AWG (7x30) stranded copper (tin plated) 0.010 in. (0.762mm) O.D.
- Insulation – Foamed FEP, 0.015 in. (0.381mm) wall, 0.060 in. (1.524mm) O.D.
- Twist Lay – 2 in. (50.8mm) lay on pair, 6 twists/foot (20 twists/meter) nominal
- Shielding – Aluminum/Mylar shield with 24 AWG (7x32) TC drain
- DC Resistance – 15.2 Ohms/1000 feet (50 Ohms/km) nominal
- Capacitance – 12.5 pF/ft (41 pF/meter) nominal conductor to conductor
- Characteristic Impedance – 100 Ohms
- Weight – 12 lb/1000 feet (17.9 kg/km)
- UL temperature rating – SmokeGard: 167°F (75°C) Halar: -40 to 302°F (-40 to 150°C)
- Voltage – 300 Vac, power limited
- UL: NEC CL2P, or better

Cable Shields

Do not ground the shield to earth ground or to the control module’s power ground. The PROT485 and the individual control modules allow the shield to float a limited amount so that there are no ground loops. If the voltage on the shield becomes too great relative to the earth ground, then the excess voltage is bled off with protective devices on the PROT485 or on the control modules.


Noise Avoidance

Avoid running communication wires or sensor input wires next to AC power wires or the control module’s relay output wires. These can be a source of noise that can affect signal quality. Common sources of noise are:

- | | |
|-------------------------|---------------------------------------|
| Spark ignitors | Induction heaters |
| Radio transmitters | Large contactors (ex. motor starters) |
| Variable speed drives | Video display devices |
| Electric motors (> 1hp) | Lamp dimmers |
| Generators | Fluorescent lights |
| Relays | Parallel runs with power lines |
| Transformers | Other electronic modules |

If noise is a problem and you cannot move the wiring, use ferrite clamp-on chokes on the cabling to improve signal quality.

Wiring Diagrams - 030, 050, 070 - Heat Pump



CLIMA COOL
 THE ULTIMATE CHILLER SOLUTION™

Elec. Diagram Module Power & Full Micro Controller
 Modular W/C Scroll Chiller UCH Heat Pump Product Family
 Motorized Valves for both Chiller & Condenser Water Flow

File No. 9680114N02
 Dwg. No. CEU-UCHxxxxxH/F/NJxxxxxx_1EDWGC E

SCALE: NONE DATE: 01/06/2015 SHEET: 1 OF 2

Wiring Diagrams - 030, 050, 070 - Heat Pump

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	
K	Chiller Model #	Fuse Block	Fuse Amps	Fuse VAC	Fuse Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps
	UCH025AH..R	FBI, FB2 CCFB3 CCFB4	80 12 3	208-230 24 208-230	LPJ LP-CC LP-CC	250	14 ga.	60	4 ga.	180 lb-h						
	UCH025AF..R	FBI, FB2 CCFB3 CCFB4	35 6 0.6	460 24 460	RK-5 LP-CC LP-CC	150	18 ga.	40	8 ga.	180 lb-h						
J	Chiller Model #	Fuse Block	Fuse Amps	Fuse VAC	Fuse Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps
	UCH025AH..R	FBI, FB2 CCFB3 CCFB4	90 12 3	208-230 24 208-230	LPJ LP-CC LP-CC	250	14 ga.	75	4 ga.	180 lb-h						
	UCH025AF..R	FBI, FB2 CCFB3 CCFB4	40 6 0.8	460 24 460	RK-5 LP-CC LP-CC	150	18 ga.	40	8 ga.	180 lb-h						
I	Chiller Model #	Fuse Block	Fuse Amps	Fuse VAC	Fuse Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps
	UCH030AH..R	FBI, FB2 CCFB3 CCFB4	175 15 4	208-230 24 208-230	N/A LP-CC LP-CC	500	14 ga.	150	2 ga.	325 lb-h						
	UCH030AF..R	FBI, FB2 CCFB3 CCFB4	70 6 0.8	460 24 460	LPJ LP-CC LP-CC	150	18 ga.	60	4 ga.	180 lb-h						
H	Chiller Model #	Fuse Block	Fuse Amps	Fuse VAC	Fuse Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps
	UCH030AH..R	FBI, FB2 CCFB3 CCFB4	60 6 0.8	575 24 575	RK-5 LP-CC LP-CC	250	18 ga.	50	8 ga.	180 lb-h						
	UCH030AF..R	FBI, FB2 CCFB3 CCFB4	35 6 0.6	575 24 575	LP-CC LP-CC LP-CC	250	18 ga.	40	10 ga.	180 lb-h						
G	Chiller Model #	Fuse Block	Fuse Amps	Fuse VAC	Fuse Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps
	UCH050AH..R	FBI, FB2 CCFB3 CCFB4	225 15 4	208-230 24 208-230	LP-CC LP-CC LP-CC	500	14 ga.	150	2 ga.	375 lb-h						
	UCH050AF..R	FBI, FB2 CCFB3 CCFB4	90 12 1.5	460 24 460	LPJ LP-CC LP-CC	250	14 ga.	75	4 ga.	180 lb-h						
F	Chiller Model #	Fuse Block	Fuse Amps	Fuse VAC	Fuse Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps
	UCH070AH..R	FBI, FB2 CCFB3 CCFB4	275 15 4	208-230 24 208-230	LP-CC LP-CC LP-CC	500	14 ga.	150	2 ga.	375 lb-h						
	UCH070AF..R	FBI, FB2 CCFB3 CCFB4	90 12 1.5	460 24 460	LPJ LP-CC LP-CC	250	14 ga.	75	4 ga.	180 lb-h						
E	Chiller Model #	Fuse Block	Fuse Amps	Fuse VAC	Fuse Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps
	UCH070AH..R	FBI, FB2 CCFB3 CCFB4	275 15 4	208-230 24 208-230	LP-CC LP-CC LP-CC	500	14 ga.	150	2 ga.	375 lb-h						
	UCH070AF..R	FBI, FB2 CCFB3 CCFB4	90 12 1.5	460 24 460	LPJ LP-CC LP-CC	250	14 ga.	75	4 ga.	180 lb-h						
D	Chiller Model #	Fuse Block	Fuse Amps	Fuse VAC	Fuse Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps
	UCH070AH..R	FBI, FB2 CCFB3 CCFB4	275 15 4	208-230 24 208-230	LP-CC LP-CC LP-CC	500	14 ga.	150	2 ga.	375 lb-h						
	UCH070AF..R	FBI, FB2 CCFB3 CCFB4	90 12 1.5	460 24 460	LPJ LP-CC LP-CC	250	14 ga.	75	4 ga.	180 lb-h						
C	Chiller Model #	Fuse Block	Fuse Amps	Fuse VAC	Fuse Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps
	UCH070AH..R	FBI, FB2 CCFB3 CCFB4	275 15 4	208-230 24 208-230	LP-CC LP-CC LP-CC	500	14 ga.	150	2 ga.	375 lb-h						
	UCH070AF..R	FBI, FB2 CCFB3 CCFB4	90 12 1.5	460 24 460	LPJ LP-CC LP-CC	250	14 ga.	75	4 ga.	180 lb-h						
B	Chiller Model #	Fuse Block	Fuse Amps	Fuse VAC	Fuse Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps
	UCH070AH..R	FBI, FB2 CCFB3 CCFB4	275 15 4	208-230 24 208-230	LP-CC LP-CC LP-CC	500	14 ga.	150	2 ga.	375 lb-h						
	UCH070AF..R	FBI, FB2 CCFB3 CCFB4	90 12 1.5	460 24 460	LPJ LP-CC LP-CC	250	14 ga.	75	4 ga.	180 lb-h						
A	Chiller Model #	Fuse Block	Fuse Amps	Fuse VAC	Fuse Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps	Line Type	Line Voltage	Line Amps
	UCH070AH..R	FBI, FB2 CCFB3 CCFB4	275 15 4	208-230 24 208-230	LP-CC LP-CC LP-CC	500	14 ga.	150	2 ga.	375 lb-h						
	UCH070AF..R	FBI, FB2 CCFB3 CCFB4	90 12 1.5	460 24 460	LPJ LP-CC LP-CC	250	14 ga.	75	4 ga.	180 lb-h						

CODE	DESCRIPTION
BL	BROWN
BR	BROWN
BL	BLUE
BL	BLUE
W	WHITE
GRY	GRAY
GRY	GRAY
GR	GREEN
GR	GREEN
P	PURPLE
P	PURPLE
OR	ORANGE

FILE NO.	SIZE	SCALE	DATE	SHEET
9480114N02	B	None	01/08/2015	2 OF 2

ELECTRICAL PANEL COMPONENT LAYOUT

LEGEND

- GRD = GROUND
- TIME DELAY RELAY
- SWITCH
- PRESSURE ACTUATED SW.
- TEMP ACTUATED SWITCH
- RELAY CONTACTS N.O. = NORMALLY OPEN
- RELAY CONTACTS N.C. = NORMALLY CLOSED
- FIELD LINE VOLTAGE WIRING
- FIELD LOW VOLTAGE WIRING


NOTES:

- COMPRESSOR MOTOR THERMALLY PROTECTED INTERNALLY.
- ALL WIRING TO THE UNIT MUST COMPLY WITH NEC AND LOCAL CODES.
- 208-230V UNITS: TRANSFORMER FACTORY WIRE FOR 208V OPERATION. TRANSFORMER FACTORY WIRE FOR 230V OPERATION.
- UCH030/070/070AH: 4-COMPRESSOR FUSES SHOWN. CIRCUIT BREAKERS ARE FOR UCH050/070/070AF.
- DISCONNECT SWITCH FOR UNIT TO BE PROVIDED BY OTHERS AND SHALL BE DISCONNECTED FROM UNIT. (SEE DATA PLATE FOR SIZING.)

Elec. Diagram Module Power & Full Micro Controller


Modular W/C Scroll Chiller UCH Heat Pump Product Family
 Motorized Valves for Both Chiller & Condenser Water Flow

Wiring Diagrams - 085 - Cooling Only




<p>CLIMA-COOL THE ULTIMATE CHILLER SOLUTION®</p> <p>This document is the sole property of ClimaCool. Without the written consent of ClimaCool Corp., Design changes to any portion of this document may occur without notice.</p>	
<p>Elec. Diagram Module Power & Full Micro Controller</p> <p>Modular W/C Scroll Chiller UCW/UCH085 Product Family</p> <p>Optional Motorized Valves for Both Chiller & Condenser Water Flow</p>	<p>SIZE File No. B 9680114003</p> <p>Dwg. No. CEL-UCW/H085AH/F/N-1-G.DWG</p> <p>REV</p>
<p>SCALE None</p> <p>DATE 05/14/15</p> <p>SHEET 1 OF 2</p>	<p>REV C</p>

Wiring Diagrams - 085 Heat Pump



CLIMA COOL		CLIMA COOL	
THE ULTIMATE CHILLER SOLUTION			
Elec. Diagram Module Power & Full Micro Controller			
Modular W/C Scroll Chiller UCH Heat Pump Product Family			
Motorized Valves for Both Chiller & Condenser Water Flow			
SIZE	FILE NO.	Dwg. No.	REV
B	9808014N06	CEL-UCH085AH/F/R/XX/XX-1DDWG	D
SCALE	None	DATE	01/08/2015
SHEET		1 OF 2	

Wiring Diagrams - 085 Heat Pump




CODE	DESCRIPTION
BR	BROWN
BL	BLUE
RD	RED
WH	WHITE
GRY	GRAY
GR/G	GREEN/WHITE
GR	GREEN
P	PURPLE
OR	ORANGE

SIZE	Fig No.	REV
B	9480114N06	CEL-UCH085A(H/F/N)XXXRX_2D.DWG
SCALE None		D
DATE 01/08/2015		2 OF 2

CODE	DESCRIPTION
CC1	Compressor 1 Circuit Breaker (In Lieu of Contactor Rating)
CC2	Compressor 2 Circuit Breaker (In Lieu of Contactor Rating)
CC3	Compressor 3 Circuit Breaker (In Lieu of Contactor Rating)
CC4	Compressor 4 Circuit Breaker (In Lieu of Contactor Rating)
CC5	Compressor 5 Circuit Breaker (In Lieu of Contactor Rating)
CC6	Compressor 6 Circuit Breaker (In Lieu of Contactor Rating)
CC7	Compressor 7 Circuit Breaker (In Lieu of Contactor Rating)
CC8	Compressor 8 Circuit Breaker (In Lieu of Contactor Rating)
CC9	Compressor 9 Circuit Breaker (In Lieu of Contactor Rating)
CC10	Compressor 10 Circuit Breaker (In Lieu of Contactor Rating)
CC11	Compressor 11 Circuit Breaker (In Lieu of Contactor Rating)
CC12	Compressor 12 Circuit Breaker (In Lieu of Contactor Rating)
CC13	Compressor 13 Circuit Breaker (In Lieu of Contactor Rating)
CC14	Compressor 14 Circuit Breaker (In Lieu of Contactor Rating)
CC15	Compressor 15 Circuit Breaker (In Lieu of Contactor Rating)
CC16	Compressor 16 Circuit Breaker (In Lieu of Contactor Rating)
CC17	Compressor 17 Circuit Breaker (In Lieu of Contactor Rating)
CC18	Compressor 18 Circuit Breaker (In Lieu of Contactor Rating)
CC19	Compressor 19 Circuit Breaker (In Lieu of Contactor Rating)
CC20	Compressor 20 Circuit Breaker (In Lieu of Contactor Rating)
CC21	Compressor 21 Circuit Breaker (In Lieu of Contactor Rating)
CC22	Compressor 22 Circuit Breaker (In Lieu of Contactor Rating)
CC23	Compressor 23 Circuit Breaker (In Lieu of Contactor Rating)
CC24	Compressor 24 Circuit Breaker (In Lieu of Contactor Rating)
CC25	Compressor 25 Circuit Breaker (In Lieu of Contactor Rating)
CC26	Compressor 26 Circuit Breaker (In Lieu of Contactor Rating)
CC27	Compressor 27 Circuit Breaker (In Lieu of Contactor Rating)
CC28	Compressor 28 Circuit Breaker (In Lieu of Contactor Rating)
CC29	Compressor 29 Circuit Breaker (In Lieu of Contactor Rating)
CC30	Compressor 30 Circuit Breaker (In Lieu of Contactor Rating)
CC31	Compressor 31 Circuit Breaker (In Lieu of Contactor Rating)
CC32	Compressor 32 Circuit Breaker (In Lieu of Contactor Rating)
CC33	Compressor 33 Circuit Breaker (In Lieu of Contactor Rating)
CC34	Compressor 34 Circuit Breaker (In Lieu of Contactor Rating)
CC35	Compressor 35 Circuit Breaker (In Lieu of Contactor Rating)
CC36	Compressor 36 Circuit Breaker (In Lieu of Contactor Rating)
CC37	Compressor 37 Circuit Breaker (In Lieu of Contactor Rating)
CC38	Compressor 38 Circuit Breaker (In Lieu of Contactor Rating)
CC39	Compressor 39 Circuit Breaker (In Lieu of Contactor Rating)
CC40	Compressor 40 Circuit Breaker (In Lieu of Contactor Rating)
CC41	Compressor 41 Circuit Breaker (In Lieu of Contactor Rating)
CC42	Compressor 42 Circuit Breaker (In Lieu of Contactor Rating)
CC43	Compressor 43 Circuit Breaker (In Lieu of Contactor Rating)
CC44	Compressor 44 Circuit Breaker (In Lieu of Contactor Rating)
CC45	Compressor 45 Circuit Breaker (In Lieu of Contactor Rating)
CC46	Compressor 46 Circuit Breaker (In Lieu of Contactor Rating)
CC47	Compressor 47 Circuit Breaker (In Lieu of Contactor Rating)
CC48	Compressor 48 Circuit Breaker (In Lieu of Contactor Rating)
CC49	Compressor 49 Circuit Breaker (In Lieu of Contactor Rating)
CC50	Compressor 50 Circuit Breaker (In Lieu of Contactor Rating)
CC51	Compressor 51 Circuit Breaker (In Lieu of Contactor Rating)
CC52	Compressor 52 Circuit Breaker (In Lieu of Contactor Rating)
CC53	Compressor 53 Circuit Breaker (In Lieu of Contactor Rating)
CC54	Compressor 54 Circuit Breaker (In Lieu of Contactor Rating)
CC55	Compressor 55 Circuit Breaker (In Lieu of Contactor Rating)
CC56	Compressor 56 Circuit Breaker (In Lieu of Contactor Rating)
CC57	Compressor 57 Circuit Breaker (In Lieu of Contactor Rating)
CC58	Compressor 58 Circuit Breaker (In Lieu of Contactor Rating)
CC59	Compressor 59 Circuit Breaker (In Lieu of Contactor Rating)
CC60	Compressor 60 Circuit Breaker (In Lieu of Contactor Rating)
CC61	Compressor 61 Circuit Breaker (In Lieu of Contactor Rating)
CC62	Compressor 62 Circuit Breaker (In Lieu of Contactor Rating)
CC63	Compressor 63 Circuit Breaker (In Lieu of Contactor Rating)
CC64	Compressor 64 Circuit Breaker (In Lieu of Contactor Rating)
CC65	Compressor 65 Circuit Breaker (In Lieu of Contactor Rating)
CC66	Compressor 66 Circuit Breaker (In Lieu of Contactor Rating)
CC67	Compressor 67 Circuit Breaker (In Lieu of Contactor Rating)
CC68	Compressor 68 Circuit Breaker (In Lieu of Contactor Rating)
CC69	Compressor 69 Circuit Breaker (In Lieu of Contactor Rating)
CC70	Compressor 70 Circuit Breaker (In Lieu of Contactor Rating)
CC71	Compressor 71 Circuit Breaker (In Lieu of Contactor Rating)
CC72	Compressor 72 Circuit Breaker (In Lieu of Contactor Rating)
CC73	Compressor 73 Circuit Breaker (In Lieu of Contactor Rating)
CC74	Compressor 74 Circuit Breaker (In Lieu of Contactor Rating)
CC75	Compressor 75 Circuit Breaker (In Lieu of Contactor Rating)
CC76	Compressor 76 Circuit Breaker (In Lieu of Contactor Rating)
CC77	Compressor 77 Circuit Breaker (In Lieu of Contactor Rating)
CC78	Compressor 78 Circuit Breaker (In Lieu of Contactor Rating)
CC79	Compressor 79 Circuit Breaker (In Lieu of Contactor Rating)
CC80	Compressor 80 Circuit Breaker (In Lieu of Contactor Rating)
CC81	Compressor 81 Circuit Breaker (In Lieu of Contactor Rating)
CC82	Compressor 82 Circuit Breaker (In Lieu of Contactor Rating)
CC83	Compressor 83 Circuit Breaker (In Lieu of Contactor Rating)
CC84	Compressor 84 Circuit Breaker (In Lieu of Contactor Rating)
CC85	Compressor 85 Circuit Breaker (In Lieu of Contactor Rating)
CC86	Compressor 86 Circuit Breaker (In Lieu of Contactor Rating)
CC87	Compressor 87 Circuit Breaker (In Lieu of Contactor Rating)
CC88	Compressor 88 Circuit Breaker (In Lieu of Contactor Rating)
CC89	Compressor 89 Circuit Breaker (In Lieu of Contactor Rating)
CC90	Compressor 90 Circuit Breaker (In Lieu of Contactor Rating)
CC91	Compressor 91 Circuit Breaker (In Lieu of Contactor Rating)
CC92	Compressor 92 Circuit Breaker (In Lieu of Contactor Rating)
CC93	Compressor 93 Circuit Breaker (In Lieu of Contactor Rating)
CC94	Compressor 94 Circuit Breaker (In Lieu of Contactor Rating)
CC95	Compressor 95 Circuit Breaker (In Lieu of Contactor Rating)
CC96	Compressor 96 Circuit Breaker (In Lieu of Contactor Rating)
CC97	Compressor 97 Circuit Breaker (In Lieu of Contactor Rating)
CC98	Compressor 98 Circuit Breaker (In Lieu of Contactor Rating)
CC99	Compressor 99 Circuit Breaker (In Lieu of Contactor Rating)
CC100	Compressor 100 Circuit Breaker (In Lieu of Contactor Rating)

Wiring Diagrams - Master Panel



Troubleshooting Guide

WARNING!

The troubleshooting guidelines recommended in this section could result in exposure to electrical safety hazards. Please refer to the safety warnings provided in this manual. Failure to follow all of the recommended safety warnings provided could result in death or serious injury. When possible,

disconnect all electrical power including remote disconnects before servicing. Follow proper lockout/tagout procedures. Only a qualified licensed electrician or persons trained to handle live electrical components should be allowed to work with energized electrical components.

Chiller Will Not Start	
Possible Cause	Remedy
Power off	Check main disconnect switch.
Main line open	Check main fuses.
Incorrect wiring	Check the wiring diagram.
Loose terminals/connections	Tighten the terminal connections.
Control circuit open	Check interlocks with auxiliary equipment, pressure and temperature controls.
Improper phasing of main power	Change any two of three phases of main power.
Compressor Hums But Does Not Start	
Possible Cause	Remedy
Low voltage	Check at main power entry and unit power entry (consult power company if low).
Phase loss	Check power wiring and fuses.
Compressor Runs But Does Not Cool	
Possible Cause	Remedy
Improper phasing of main power	Switch any two of three phases of main power.
Compressor Cuts Out On Low Pressure Safety Control	
Possible Cause	Remedy
Main chilled water valve closed or restricted	Open valve to full open position.
Module chilled water isolation valves, if provided, closed or restricted	Open valves to full open position.
Refrigerant storage	Check for leaks – add refrigerant.
No load on water chiller	Check water pump operation.
Restriction in liquid line	Plugged liquid line drier – replace liquid line drier.
Expansion valve clogged or inoperative	Repair/replace the expansion valve.
Low discharge pressure	Raise and control discharge pressure within design limits.
Low water flow through the cooler	Check water flow through the cooler.
Chilled water temperature too cold	Raise water temperature setpoint.
Fouled evaporator brazed plate heat exchanger	Clean-in-place heat exchanger as described in IOM (page 32).
Improper chilled water circulation	Use an ample sized cleanable strainer in the chilled water circuit; make certain the strainer is clean to insure full flow of chilled water (strainer screen must be 60 mesh minimum).
Faulty suction pressure transducer	Verify transducer calibration using a calibrated manifold gauge and replace if defective.
Wrong suction pressure cutout setpoint	Verify suction pressure cutout setpoint to be set equal to the corresponding leaving chilled solution freeze temperature equivalent pressure on a PT chart. (i.e. If the solution freeze point is 32°F, the equivalent pressure setpoint will be 101 psig).

Troubleshooting Guide

Compressor Cycle On High Pressure Control	
Possible Cause	Remedy
Main condenser water valve closed or restricted	Open valve to full open position.
Module condenser water isolation valves, if provided, closed or restricted	Open valves to full open position.
Water regulating valve incorrectly set or defective	Reset or replace.
Compressor discharge valve partially closed	Open valve to full open position.
Non-condensable gases in hydronic system	Recover non-condensable gases from bleed valve on condenser or at bleed valve of the building condenser water system.
Overcharge of refrigeration	Recover refrigerant from system while in operation until the first sign of bubbles are shown in the sight glass. Add back refrigerant just until bubbles clear.
Condenser water temperature high	Check water supply temperature against requirements; if cooling tower is used check spray nozzles on cooling tower.
Improper condenser water circulation	Use an ample sized cleanable strainer in the condenser water circuit; make certain the strainer is clean to insure full flow of condenser water (strainer must be 60 mesh minimum). It may sometimes be necessary to treat water to prevent formation of deposits.
Insufficient water flow through the condenser	Check water flow through condenser against design requirements.
Fouled condenser brazed plate heat exchanger	Clean-in-place heat exchanger as described in IOM (page 32).
Defective high pressure switch	Replace high pressure switch.
Causes and Prevention of Freeze-Ups	
Possible Cause	Remedy
Improper charging	Charge per ClimaCool data plate information, located on the chiller, following the Superheat and Subcooling procedure described in IOM (page 29).
Improper chilled water circulation	Use an ample sized cleanable strainer in the chilled water circuit; make certain the strainer is clean to insure full flow and velocity of chilled water (strainer screen must be 60 mesh minimum). It may sometimes be necessary to treat water to prevent formation of deposits.
Not draining for winter shutdown	When the system is shut down for the winter, remove the drain plugs from the flush ports and drain the cooler. Blow out remaining water with air.
Faulty leaving chilled solution temperature	Verify sensor calibration using a calibrated thermometer and replace if defective.
Wrong freeze-up protection temperature setpoint	Verify leaving chilled solution freeze protection temperature setpoint to be set at 8°F above solution freeze point.

Note: See page 44 for Troubleshooting for Stainless Steel Strainer ATF Package.

ATTENTION

To avoid the release of refrigerant into the atmosphere, the refrigerant circuit of this unit must be serviced only by technicians who meet local, state and federal proficiency requirements.

All refrigerant discharged from this unit must be recovered **WITHOUT EXCEPTION**. Technicians must follow industry accepted guidelines and all local, state and federal statutes for the recovery and disposal of refrigerants.

If a compressor is removed from the unit, system refrigerant circuit oil will remain in the compressor. To avoid leakage of compressor oil, the refrigerant lines of the compressor must be sealed after it is removed.

WARNING/AVERTISSEMENT

Disconnect power supply (ies) before servicing. Refer servicing to qualified service personnel. Electric shock hazard. May result in injury or death!		Debrancher avant d'entreprendre le dépannage de l'appareil. Consulter un réparateur qualifié pour le dépannage. Risque de choc électrique. Résultat de mal dans dommages ou la mort!
CAUTION/ATTENTION		
Unit to be serviced by qualified personnel only. Refrigerant system under pressure. Relieve pressure before using torch. Recover refrigerant and store or dispose of properly.		Conifer la maintenance à un technicien qualifié. Le système frigorifique sous pression. Décompresser avant d'exposer à la flamme. Récupérer le frigorigène et le stocker ou le détruire correctement.

Warranty Certificate



CLIMACOOL CORPORATION LIMITED EXPRESS WARRANTY/LIMITATION OF REMEDIES AND LIABILITY WITH EXTENDED COMPRESSOR WARRANTY

WARRANTY DISCLAIMER

It is expressly understood that unless a statement is specifically identified as a warranty, statements made by ClimaCool Corp., an Oklahoma corporation ("CC"), or its representatives, relating to CC's products, whether oral, written or contained in any quote, sales literature, catalog or any agreement, are not express warranties and do not form a part of the basis of the bargain, but are merely CC's opinion or commendation of CC's products. **EXCEPT AS SPECIFICALLY SET FORTH HEREIN, THERE IS NO EXPRESS WARRANTY AS TO ANY OF CC'S PRODUCTS. CC MAKES NO WARRANTY AGAINST LATENT DEFECTS. CC MAKES NO WARRANTY OF MERCHANTABILITY OF THE GOODS OR OF THE FITNESS OF THE GOODS FOR ANY PARTICULAR PURPOSE.**

GRANT OF LIMITED EXPRESS WARRANTY

CC warrants CC's product is purchased and retained in the United States of America and Canada to be free from defects in material and workmanship under normal use and maintenance only as follows:

FOR MODULAR CHILLERS: (a) All modular chillers built or sold by CC for twelve (12) months from the date of unit start-up or eighteen (18) months from date of shipment (from CC's warehouse), whichever comes first; and (b) Any repair and replacement parts, which are not supplied under warranty, for ninety (90) days from date of shipment (from CC's warehouse) and (c) If such extended warranty is purchased, the compressors in all modular chillers built or sold by CC shall extend for sixty (60) months from the date of shipment (from CC's warehouse).

FOR ROOF TOP UNITS: (a) All roof top units built or sold by CC for twelve (12) months from the date of unit start-up or eighteen (18) months from date of shipment (from CC's warehouse), whichever comes first; (b) All compressors supplied by CC with CC's roof top units for sixty (60) months from date of shipment (from CC's warehouse); (c) All gas fired stainless steel heat exchangers supplied by CC with CC's roof top units for ten (10) years from date of shipment (from CC's warehouse); and (d) Any repair and replacement parts, which are not supplied under warranty, for ninety (90) days from date of shipment (from CC's warehouse).

All parts must be returned to CC's warehouse in Oklahoma City, Oklahoma, freight prepaid, no later than sixty (60) days after the date of the failure of the part. If CC determines the part to be defective and within CC's Limited Express Warranty, CC shall, when such part has been either replaced or repaired, return such to a CC recognized dealer, contractor or service organization, F.O.B. CC's warehouse, Oklahoma City, Oklahoma, freight prepaid. The warranty on any part repaired or replaced under warranty expires at the end of the original warranty period.

This warranty does not cover and does not apply to: (1) Fuses, refrigerant, fluids, oil; (2) Products relocated after initial installation; (3) Any portion or component of the system that is not supplied by CC, regardless of the cause of the failure of such portion or component; (4) Products on which the units identification tags or labels have been removed or defaced; (5) Products on which payment to CC is or has been in default; (6) Products which have defects or damage which result from improper installation, wiring, electrical imbalance characteristics or maintenance (including, without limitation, defects or damages caused by voltage surges, inadequate voltage conditions, phase imbalance, any form of electrical disturbances, inadequate or improper electrical circuit installation or protection, failure to perform common maintenance, etc.); or are caused by accident, misuse or abuse, fire, flood, alteration or misapplication of the product; (7) Products which have defects or damage which result from a contaminated or corrosive air or liquid supply, operation at abnormal temperatures, or unauthorized opening of refrigerant circuit; (8) Products subjected to corrosion or abrasion or chemicals; (9) Mold, fungus or bacteria damage; (10) Products manufactured or supplied by others; (11) Products which have been subjected to misuse, negligence or accidents; (12) Products which have been operated in a manner contrary to CC's printed instructions; (13) Products which have defects, damage or insufficient performance as a result of insufficient or incorrect system design or the improper application of CC's products; (14) Products which have defects or damages due to freezing of the water supply, an inadequate or interrupted water supply, corrosives or abrasives in the water supply, or improper or inadequate filtration or treatment of the water or air supply; (15) Products which are affected caused by overfiring, use of incorrect fuel, or improper burn or control adjustments; or (16) Products which have incomplete or inadequate combustion.

CC is not responsible for: (1) The costs of any fluids, refrigerant or other system components, or the associated labor to repair or replace the same, which is incurred as a result of a defective part covered by CC's Limited Express Warranty; (2) The costs of labor, refrigerant, materials or service incurred in removal of the defective part, or in obtaining and replacing the new or repaired part; or, (3) Transportation costs of the defective part from the installation site to CC or the return of any part not covered by CC's Limited Express Warranty.

Limitation: This Limited Express Warranty is given in lieu of all other warranties. If, notwithstanding the disclaimers contained herein, it is determined that other warranties exist, any such warranty, including without limitation, any express warranties or any implied warranties of fitness for any particular purpose and merchantability, shall be limited to the duration of the Limited Express Warranty.

LIMITATION OF REMEDIES

In the event of a breach of this Limited Express Warranty, CC will only be obligated at CC's option to repair the failed part or module or to furnish a new or rebuilt part or module in exchange for the part or module which has failed. If, after written notice to CC's Head Office in Oklahoma City, Oklahoma of each defect, malfunction or other failure and a reasonable number of attempts by CC to correct the defect, malfunction or other failure and the remedy fails of its essential purpose, CC shall refund the purchase price paid to CC in exchange for the return of the sold goods. Said refund shall be the maximum liability of CC. **THIS REMEDY IS THE SOLE AND EXCLUSIVE REMEDY AGAINST CC FOR BREACH OF CONTRACT, FOR THE BREACH OF ANY WARRANTY OR FOR CC'S OWN NEGLIGENCE OR IN STRICT LIABILITY.**

LIMITATION OF LIABILITY

CC shall have no liability for any damages if CC's performance is delayed for any reason or is prevented to any extent by any event such as, but not limited to any, war, civil unrest, government restrictions or restraints, strikes, or work stoppages, fire, flood, accident, allocation, shortages of transportation, fuel, material or labor, acts of God or any other reason beyond the sole control of CC. **CC EXPRESSLY DISCLAIMS AND EXCLUDES ANY LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGE IN CONTRACT, FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, OR IN TORT, WHETHER FOR CC'S OWN NEGLIGENCE OR AS STRICT LIABILITY.**

OBTAINING WARRANTY PERFORMANCE

Normally, the contractor or service organization who installed the products will provide warranty performance for the owner. Should the installer be unavailable, contact any CC recognized contractor or service organization. If assistance is required in obtaining warranty performance, write:

ClimaCool Corp. • P.O. Box 2055 • Oklahoma City, Oklahoma 73101 • (405) 815-3000 • e-mail: Claims@climacoolcorp.com

NOTE: Some states or Canadian provinces do not allow limitations on how long an implied warranty lasts, or the limitation or exclusion of consequential or incidental damages, so the foregoing exclusion and limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state and from Canadian province to Canadian province. Please refer to the CC Installation, Operation and Maintenance Manual for operating and maintenance instructions.

forms\ccool\standard forms\word files\Cool warranty compressor certificate 07-17-14



www.climacoolcorp.com



CLIMACOOL
THE ULTIMATE CHILLER SOLUTION[®]

15 S. Virginia
Oklahoma City, OK 73106
Phone: 405-815-3000
Fax: 405-815-3052
www.climacoolcorp.com



ClimaCool works continually to improve its products. As a result, the design and specifications of each product at the time for order may be changed without notice and may not be as described herein. Please contact ClimaCool's Customer Service Department at 405-815-3000 for specific information on the current design and specifications. Statements and other information contained herein are not express warranties and do not form the basis of any bargain between the parties, but are merely ClimaCool's opinion or commendation of its products.

AHRI Certified™ is a trademark of the Air Conditioning, Heating, and Refrigeration Institute. 'USGBC®' and related logo is a trademark owned by the U.S. Green Building Council® and is used with permission.